



**User's Manual**

**3301570**

## Revision History

<b>Title</b>	<b>3301570 Intel Pentium D/Pentium 4 LGA775 CPU board</b>	
<b>Revision Number</b>	<b>Description</b>	<b>Date of Issue</b>
<b>1.0</b>	<b>Initial release</b>	<b>March 2006</b>

## Copyright Notice

The information in this document is subject to change without prior notice in order to improve reliability, design and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

## Trademarks

IBM PC is a registered trademark of International Business Machines Corporation. INTEL is a registered trademark of INTEL Corporation. AMI is registered trademarks of American Megatrends Inc. Other product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

## Table of Contents

Revision History .....	2
Copyright Notice.....	2
Trademarks.....	2
Table of Contents.....	3
Safety Notice .....	9
ESD Precautions.....	9
Conventions Used in This Manual .....	9
Software and Firmware Updates .....	10
 <b>CHAPTER 1 INTRODUCTION</b>	
<b>Product Overview .....</b>	<b>1-2</b>
The CPU Board .....	1-2
The Backplanes.....	1-3
PCI-E x1 speed.....	1-3
<b>3301570 Board Overview.....</b>	<b>1-4</b>
Technical Specifications .....	1-5
System Monitoring.....	1-7
 <b>CHAPTER 2 FUNCTIONAL DESCRIPTION</b>	
<b>2.1 CPU, Memory, and Intel Chipsets.....</b>	<b>2-2</b>
CPU.....	2-2
Memory .....	2-3
Intel 945G Express Chipset.....	2-3
<b>Block Diagram.....</b>	<b>2-4</b>
<b>Features.....</b>	<b>2-5</b>
PCI Express x16 as graphics or I/O channel .....	2-5
<b>2.2 External Interfaces.....</b>	<b>2-6</b>
List of All Interface Connectors.....	2-7

<b>2.2.1 Internal Connectors</b> .....	<b>2-7</b>
<b>2.2.2 Rear Panel Connectors</b> .....	<b>2-16</b>

## **CHAPTER 3 INSTALLATION**

<b>3.1 Considerations Prior to Installation</b> .....	<b>3-2</b>
Preparing Your CPU Board .....	3-2
Installation Notices .....	3-2
Dual Channel Memory Configuration .....	3-3
HT functionality requirements content .....	3-3
<b>Unpacking Precautions</b> .....	<b>3-4</b>
<b>3.2 Jumper Settings</b> .....	<b>3-5</b>
JP1 (Clear CMOS) .....	3-5
JP1 Pin Configuration .....	3-6
<b>External Switches and Indicators</b> .....	<b>3-7</b>
CN1 (PWR/HDD LED/SW/SPK/RST Pins) .....	3-7
CN1 Pinouts .....	3-7
<b>3.3 Installation</b> .....	<b>3-8</b>
<b>CPU Installation</b> .....	<b>3-8</b>
<b>Cooling Kit (CF-520) Installation</b> .....	<b>3-12</b>
<b>DIMM Installation</b> .....	<b>3-13</b>
<b>Connections to the Peripherals</b> .....	<b>3-13</b>

## **CHAPTER 4 AMI BIOS SETUP**

<b>Introduction</b> .....	<b>4-2</b>
<b>Starting Setup</b> .....	<b>4-2</b>
<b>Using Setup</b> .....	<b>4-2</b>
<b>Getting Help</b> .....	<b>4-3</b>
<b>BIOS Menu Bar</b> .....	<b>4-4</b>
<b>4.1 Main</b> .....	<b>4-5</b>
<b>4.2 Advanced</b> .....	<b>4-6</b>

CPU Configuration .....	4-7
IDE Configuration .....	4-8
Floppy Configuration .....	4-11
Super IO Configuration.....	4-11
Hardware Health Configuration.....	4-13
CPU Fan Target Temperature.....	4-13
ACPI Configuration.....	4-14
APM Configuration .....	4-16
MPS Configuration .....	4-18
Remote Access Configuration .....	4-18
USB Configuration.....	4-18
<b>PCIPnP.....</b>	<b>4-20</b>
Clear NVRAM .....	4-20
Plug & Play O/S.....	4-20
PCI Latency Timer .....	4-21
Allocate IRQ to PCI VGA .....	4-21
Palette Snooping .....	4-21
PCI IDE BusMaster.....	4-21
OffBoard PCI/ISA IDE Card .....	4-21
IRQ#   4-21	
DMA Channel# .....	4-22
Reserved Memory Size .....	4-22
<b>Boot .....</b>	<b>4-23</b>
Bootup Num-Lock [On].....	4-24
Boot Device Priority.....	4-24
Hard Disk Drives.....	4-25
Removable Drives .....	4-25
<b>Security.....</b>	<b>4-26</b>
<b>Chipset.....</b>	<b>4-27</b>
North Bridge Configuration.....	4-27
South Bridge Chipset Configuration.....	4-29
<b>Exit .....</b>	<b>4-30</b>

**CHAPTER 5 USB 2.0 CONFIGURATION**

5.1	Introduction.....	5-2
5.2	Installation .....	5-2

**APPENDIX A WATCHDOG TIMER**

<b>AH – 6FH Sub-function:</b> .....	A-2
-------------------------------------	-----

**APPENDIX B ADDRESS MAPPING**

B.1	IO Address Map .....	B-2
B.2	1st MB Memory Address Map .....	B-2
B.3	IRQ Mapping Table .....	B-3
B.4	DMA Channel Assignments.....	B-3

**APPENDIX C ATX POWER SUPPLY****APPENDIX D INTEL RAID FOR SATA****APPENDIX E EXTERNAL AC'97 AUDIO CODEC**

## List of Tables

Table 1-1	Backplane Options .....	3
Table 1-2	Technical Specifications .....	7
Table 2-1	Supported CPUs .....	2
Table 2-2	Important Features .....	5
Table 2-3	Interface Connectors.....	7
Table 2-4	CPU12V - CPU Power Connector Pinouts .....	7
Table 2-5	IR1 IrDA Interface Port Pinouts .....	8
Table 2-6	ATXCTL Control Pinouts .....	8
Table 2-7	Fan1 Connector Pinouts .....	8
Table 2-8	IDE Connector Pinouts.....	9
Table 2-9	FDD Port Pinouts .....	10
Table 2-10	LPT1 Parallel Port Pinouts .....	11
Table 2-11	DIO1 Digital I/O Header Pinouts .....	12
Table 2-12	CN2 KB/MS Connector Pinouts .....	12
Table 3-1	JP1 Pin Configuration .....	6
Table 3-2	CN1 Pinouts .....	7
Table 3-3	Cables Included in Kit .....	14
Table 4-1	BIOS Function Keys.....	3
Table A-1	AH-6FH Sub-function .....	1
Table B-1	IO Address Map .....	2
Table B-2	1 <sup>st</sup> MB Memory Address Map.....	2
Table B-3	IRQ Mapping Table.....	3
Table B-4	DMA Channel Assignments.....	3

## List of Figures

Figure 1-1	3301570 Board Overview.....	4
Figure 2-1	System Block Diagram.....	4
Figure 2-2	External Interface Locations.....	6
Figure 2-3	CPU12V .....	7
Figure 2-4	IR1 IrDA Interface Port.....	8
Figure 2-5	ATXCTL Control .....	8
Figure 2-6	Fan1 Power Source .....	8
Figure 2-7	IDE Connector.....	9
Figure 2-8	FDD Port .....	10
Figure 2-9	LPT1 Parallel Port .....	11
Figure 2-10	DIO1 Digital I/O Header .....	12
Figure 2-11	CN2 KB/MS Connector .....	12
Figure 2-12	COM Port .....	13
Figure 2-13	Serial ATA Port .....	14
Figure 2-14	Audio01 Audio Port .....	14
Figure 2-15	USB Port.....	15
Figure 2-16	CPU_FAN connector.....	15
Figure 2-17	Rear Panel Connectors.....	16
Figure 2-18	PS/2 KB/MS Port.....	16
Figure 2-19	GbE Ethernet LAN (RJ-45) Port.....	17
Figure 3-2	JP1 Jumper Location .....	5
Figure 3-3	CN1 Connector Location.....	7
Figure 3-4	Intel 775-pin Socket .....	8
Figure 3-5	775 Socket Protective Cover.....	9
Figure 3-6	Load Lever and Load Plate at the Fully Open Position .....	9
Figure 3-7	Orienting CPU .....	10
Figure 3-8	Cooling Kit .....	12
Figure 3-9	Heatsink and the Support Bracket .....	13
Figure 3-10	ATX Control Connection.....	15
Figure C-1	ATX Power Connection .....	1
Figure C-2	ATX Power Switch.....	2
Figure E-1	Audio Functionalities via the Audio Kit .....	2
Figure E-1	Audio Kit Connectors .....	3

## Safety Notice

Electrical shock hazards might occur while proceeding with the installation, repair and maintenance of this product. Therefore, the following precaution measures should be carefully observed:

1. All sorts of operations on this product must be carried out by certified technicians.
2. The chassis into which the CPU board and its associated backplane are installed should provide stable power supply and be properly grounded.
3. Power off the CPU board and unplug its power cord before handling.
4. When handling the CPU board, avoid touching any metal leads or connectors.
5. Please verify that the power supply is switched off before unplugging the power supply connector from the CPU board.

## ESD Precautions

Observe all conventional anti-ESD methods while handling the CPU board. The use of a grounded wrist strap and an anti-static work pad is recommended. Avoid dust and debris or other static-accumulating materials in your work area.

## Conventions Used in This Manual

### Naming

From this point on and throughout the rest of this manual, the EonStor A24F is referred to as simply the “subsystem” or the “system.”



### **WARNING**

Warnings appear where overlooked details may cause damage to the equipment or result in personal injury. Warnings should be taken seriously. Warnings are easy to recognize. The word “warning” is written as “**WARNING**,” both capitalized and bold and is followed by text in italics. The italicized text is the warning message.

**CAUTION**

Cautionary messages should also be heeded to help you reduce the chance of losing data or damaging the system. Cautions are easy to recognize. The word “caution” is written as “**CAUTION**,” both capitalized and bold and is followed by text in italics. The italicized text is the cautionary message.

**NOTE**

These messages inform the reader of essential but non-critical information. These messages should be read carefully as any directions or instructions contained therein can help you avoid making mistakes. Notes are easy to recognize. The word “note” is written as “**NOTE**,” both capitalized and bold and is followed by text in italics. The italicized text is the cautionary message.

**Lists**

**Bulleted Lists:** Bulleted lists are statements of non-sequential facts that can be read in any order. Each statement is preceded by a round or square black dot.

**Numbered Lists:** Numbered lists describe sequential steps you should follow in order.

## Software and Firmware Updates

Please contact your system vendor for the latest software or firmware updates. **NOTE** that the BIOS version and associated drivers installed on your system should provide the complete functionality listed in the specification sheet/user’s manual. We provide special revisions for various application purposes. Therefore, **DO NOT** upgrade your BIOS unless you fully understand what a firmware revision will do.

Problems that occur during the updating process may cause unrecoverable errors and system down time. Always consult technical personnel before proceeding with any firmware upgrade.

Chapter

1

# Introduction

---

## Product Overview

### The CPU Board

The 3301570 is a highly-integrated PCI-E board designed to support Pentium® D and Pentium® 4 processors, which boost system performance for multi-processing and data-intensive application environments. Combined with Intel® 945G Express chipset and the ICH7R controller hub, the 3301570 delivers high performance through perfect integration of the latest technologies. The supported CPU speed ranges from 2.66GHz to 3.8GHz.

The CPU board comes with an unprecedented number of four (4) DDRII SDRAM sockets, which allow a large buffer and flexible configuration. The maximum memory speed supported reaches 1066MHz.

The 3301570 provides two (2) PCI-E GbE Ethernet ports, seven (7) USB 2.0, two (2) COM ports, four (4) SATA ports, various interfaces for Infrared, IDE, LPT, and Intel Graphics Media Accelerator 950 through one (1) 15-pin VGA connector. With the connection to multiple SATA-II hard drives and Intel's embedded support for RAID configurations, data distribution is safe, efficient, and smartly managed.

The 3301570 is built on PICMG specification 1.3, which features a significant improvement of bandwidth and expandability by replacing the single-board-to-backplane interface with high-speed serial links.

OSes tested and proved compliant include: DOS 6.22, Windows 2000, Windows XP, Red Hat 9.0, and SuSe 9.0.

## The Backplanes

There are two standard backplane models available with the 3301570: PE-6S and PE-10S.

Each backplane model features a combination of different interface slots:

PE-10S	PE-6S
One (1) PCI-E X16 slot	One (1) PCI-E X16 slot
One (1) PCI-E x4 slot - OR -	One (1) PCI-E x4 slot - OR -
Three (3) PCI-E x1 slot	One (1) PCI-E x1 slot
Four (4) PCI slots	Two (2) PCI slots

**Table 1-1 Backplane Options**



### NOTE:

The PCI-E x4 bus and the PCI-E x1 buses cannot be used simultaneously. A configuration jumper is provided on the backplanes, which allows you to select a bus speed of either PCI-E x4 bus or PCI-E x1 bus. Note that if PCI-E x1 speed is selected, the PCI-E x4 slot is backward compatible and can be installed with one PCI-E x1 interface card. However, when set to the PCI-E x4 speed, the PCI-E x1 slots will be disabled.

Both backplane models draw power from ATX power connectors.

### 3301570 Board Overview




Figure 1-1 3301570 Board Overview

## Technical Specifications

CPU (LGA 775)	<ul style="list-style-type: none"> <li>z Supports Intel® Pentium® D / Pentium® 4 LGA775 CPU.</li> <li>z Supports Front Side Bus at 1066/800/533MHz.</li> <li>z The size of L2 cache varies with CPU processor.</li> </ul>
Chipset	<ul style="list-style-type: none"> <li>z Northbridge: Intel® 945G Express Chipset</li> <li>z Southbridge: Intel® ICH7R</li> </ul>
Memory	<ul style="list-style-type: none"> <li>z 4 DDR II DIMM memory slots (supports up to 4GB memory)</li> <li>z Supports 1.8V DDR II DIMM</li> <li>z Supports dual channel DDR II 533/667</li> <li>z Supports one or two 64-bit wide DDRII data channels</li> <li>z Supports non ECC/ unbuffered DIMMs</li> <li>z Supports 256-Mb, 512-Mb and 1-Gb technologies for X8 &amp; X16</li> <li>z By using 1-Gb technology in dual channel interleaved mode, the largest memory capacity possible is 8GB. This exceeds a 32-bit address limit of 4 GB. In a 32-bit system, only the first 4 GB of memory will be accessible.</li> <li>z The GMCH contains one 16X PCIE port intended for an external</li> </ul>
PCI and PCI Express Interface	<ul style="list-style-type: none"> <li>z PCI Express graphics card. It connects to backplane using Connector A and Connector B in SHB.</li> <li>z The ICH7R provides two PCIE onboard GbE LAN with Marvell 88E8053</li> <li>z The ICH7R contains four 1X PCIE port through Connector A to connect to a backplane.</li> <li>z Ports 1 to 4 can be statically configured as 4X1, or 1X4, increasing flexibility for system integration. Provides four PCI master to Connector D</li> <li>z Supports PCI Rev 2.3 Specification at 33 MHz</li> </ul>
IDE interface	<ul style="list-style-type: none"> <li>z Up to two PCI Enhanced IDE hard drives. The Ultra DMA 100 IDE can handle data transfer up to 100MB/s. Compatible with existing ATA IDE specifications with its best advantages, so there is no need to do any changes with users' current accessories.</li> <li>z Supports Ultra ATA /100 / 66 / 33, BMIDE and PIO modes</li> </ul>
Graphics	<ul style="list-style-type: none"> <li>z 3D Graphics Rendering Enhancements 16- and 24-bit Z buffering</li> <li>z 16- and 32-bit Color</li> <li>z Max. resolution is 1600 x 1200 x 32 @ 85 Hz</li> </ul>

	<ul style="list-style-type: none"> <li>z 2D Graphics Optimized 256-bit BLT Engine</li> <li>z 8-, 16- and 32-bit Color</li> <li>z Video DVD/PC-VCR</li> <li>z H/W Motion Compensation for MPEG2</li> <li>z Software DVD At 30 fps, Full Screen</li> <li>z Support 720 x 480 DVD Quality Encoding at low CPU utilization for PC-VCR uses or home</li> </ul>
Floppy disk drive interface	<ul style="list-style-type: none"> <li>z Supports up to two floppy disk drives, 5.25”(360KB and 1.2MB) and/or 3.5” (720KB, 1.44MB, and 2.88MB)</li> </ul>
Serial ports	<ul style="list-style-type: none"> <li>z Two RS-232 ports with 16C550 UART (or compatible) with 16-byte FIFO buffer. Support up to 115.2Kbps. Ports can be individually configured to COM1, COM2 or disabled.</li> </ul>
Peripherals	<ul style="list-style-type: none"> <li>z 1 parallel port supporting Normal/EPP/ECP mode <ul style="list-style-type: none"> <li>- Provided as one 26-pin Printer port header</li> <li>- Supports EPP and ECP modes.</li> </ul> </li> <li>z 1 VGA port,</li> <li>z 7 USB 2.0/1.1 ports (Bracket x 1, front x 6 via cable)</li> <li>z 1 PS/2 keyboard / Mouse port</li> <li>z 1 IrDA header supports IrDAs version 1.0 SIR protocol with maximum baud rate up to 115.2K bps.</li> <li>z Digital IO: provides one 10-pin header for four GPI and four GPO</li> </ul>
Hardware monitor	<ul style="list-style-type: none"> <li>z System voltage detection</li> <li>z CPU temperature detection</li> <li>z CPU / System fan speed detection</li> <li>z CPU smart fan control</li> </ul>
IrDA port	<ul style="list-style-type: none"> <li>z Supports Serial Infrared (SIR) and Amplitude Shift Keyed IR (ASKIR) interface</li> </ul>
USB 2.0/1.1 port	<ul style="list-style-type: none"> <li>z Supports seven USB 2.0/1.1 ports for future expansion</li> </ul>
Serial ATA	<ul style="list-style-type: none"> <li>z Supports Four independent serial ATA channels. Serial ATA generation 1 transfer rate of 3Gb/s.</li> </ul>
Ethernet	<ul style="list-style-type: none"> <li>z Dual Marvell 88E8053 gigabit Ethernet controller. It is equipped for the support of full-bandwidth 100/1000BaseT Ethernet.</li> </ul>

I/O Controller	z	Winbond 8362THF	
BIOS	z	Use of licensed AMI BIOS	
Operating temperature	z	0° to 60° C (*CPU needs cooler & silicone heat sink paste* )	
Form Factor	z	PICMG 1.3 form factor	
<b>High Definition Audio and AC '97 interface</b>	z	Provides 10-pin Audio header.	
	z	HD audio interface allows for non to 48kHz sampling output.	
	z	Supports multi-channel, 32-bit sample depth, 192 kHz sample rate output.	
	z	AC-Link for Audio and Telephony CODECs; support for three AC '97 2.3 CODECs.	
<b>Power Consumption</b>	9A	@+12V	Configuration: Pentium D 3.73GHz/1066MHz CPU, with 4GB DDRII 677MHz DIMMs
	2.6A	@+5V	
	6.3A	@+3.3V	
	0.93A	@5VSB	
	0.1A	@-12V	

**Table 1-2 Technical Specifications**

## System Monitoring

The CPU board is capable of self-monitoring various aspects of its operating status including:

- „ CPU, chipset, and battery voltage, +3.3V, +5V, and +12V
- „ RPM of cooling fans
- „ CPU and board temperatures (by the corresponding embedded sensors)

This page is intentionally left blank

Chapter

**2**

# Functional Description

---

This chapter provides a functional description of the 3301570 CPU board designed for the integration with GAI backplanes and chassis. This chapter includes information about main processors, interface connectors, implementation options, and signal description.

## 2.1 CPU, Memory, and Intel Chipsets

### CPU

The 3301570 comes with an LGA775 socket for Intel Pentium D and Pentium 4 processors running at the speed ranging from 2.66 to 3.8GHz. The CPU applied requires active cooling by a heatsink and cooler.

Shown below are some of the key features of the Intel processors (taking Pentium D as an example):

- z Dual-Core processing as the main performance enhancement feature
- z Enhanced Intel SpeedStep technology for low power consumption
- z On-die two 16KB data caches as Level 1; 2MB L2 for faster I/O turnarounds
- z Extended Memory 64 technology
- z Streaming SIMD Extension 3: extra cache ability instructions for acceleration of digital media applications.

The table below provides information on the Intel processors supported on the 3301570 CPU board.

Mfg.		Model	Capacity/Speed	Description
Intel	Dual core	820	Pentium 4 2.8GHz	FSB: 800MHz
Intel	Dual core	840	Pentium 4 3.2GHz	FSB: 800MHz
Intel		820	Pentium 4 2.8GHz	FSB: 800MHz
Intel			Pentium 4 3.73GHz	SB: 1067MHz
Intel	Dual core		Pentium 4 3.8GHz	FSB: 800MHz
Intel			Pentium 4 2.66GHz	FSB: 533MHz

**Table 2-1 Supported CPUs**

## Memory

The 3301570 provides four (4) DDR2 SDRAM sockets without ECC support for building a large buffer size of up to 4GB (1GB x4). The memory is automatically identified. The memory speed can range from DDR2-400, DDR2-533, to DDR2-667.

## Intel 945G Express Chipset

The Intel 945G chipset is comprised of the following devices:

- z Intel 82945G Graphics and Memory Controller Hub
- z Intel ICH7R I/O Controller Hub

The north bridge 82945G controller hub provides processor and memory bus interfaces with an embedded graphics accelerator. The chipset provides high-bandwidth interfaces such as PCI-E x16 graphics or I/O, PCI-E x1 I/O ports, Serial ATA (SATA-II), and high speed USB 2.0 connectivity as shown in the diagram below.

## Block Diagram




Figure 2-1 System Block Diagram

## Features

Other functionalities provided by the chipset are listed below:

- 
- z Intel long term support product

---

  - z Interface: PICMG 1.3 compliant, PCI Express, PCI/PCI-X support

---

  - z PCI Express x16 as graphics or I/O channel

---

  - z System Memory: Dual channel DDR2-533/667 delivers up to 10.7GB/s bandwidth and 4GB memory addressability

---

  - z Intel Matrix Storage technology provides protection and access rate through RAID levels 0, 1, 5, and 10

---

  - z Native Command Queuing for faster boot-up and file transfer

---

  - z Six (6) PCI masters provides generous system expandability

---

  - z Up to four (4) PCI-E ports which are configurable as:
    - z One (1) PCI-E x4 port
    - or -
    - z Four (4) PCI-E x1 ports

---

  - z Hardware Monitor: Built-in to monitor CPU Vcore, VCC, CPU/System fan speed, and temperature detection functionalities.

---

  - z Independent DMA audio engines

---

  - z Ethernet: Marvell 88E8053 Gigabit Ethernet

---

**Table 2-2 Important Features**



**NOTE:**

The bus speed selection of the PCI-E ports is configured through a jumper switch on the associated backplanes.

## 2.2 External Interfaces

For the locations of external interfaces, please refer to the diagram below:




Figure 2-2 External Interface Locations

### List of All Interface Connectors

Connector	No.	Type
CPU12V	1	4-pin +12 power connector
IrDA	1	1 x 5 pin header
ATXCTL	1	3-pin header
Aux. fan	1	3-pin header
IDE	1	ATA-100 40-pin connector
FDD	1	34-pin floppy connector
LPT	1	2 x 13 pin header
VGA	1	15-pin VGA
USB2.0	1	USB connector
GbE	2	RJ-45 GbE LAN connector
KB/MS	1	PS/2 mini-bin
DIO	1	2 x 5 pin connector
COM	2	2 x 5 pin header
SATA	4	SATA-II connector
Audio	1	2 x 5 pin connector
USB2.0	3	2 x 4 pin connector
CPU_fan	1	4-pin header
KB/MS	1	6-pin auxiliary header

**Table 2-3 Interface Connectors**

## 2.2.1 Internal Connectors

### 1. CPU 12V

The CPU12V power connector main supplies power to the CPU. If the CPU12V1 power connector is not connected, the system will not start.

PIN	DESCRIPTION	PIN	DESCRIPTION
1	GND	2	GND
3	+12V	4	+12V




Figure 2-3 CPU12V

Table 2-4 CPU12V - CPU Power Connector Pinouts

### 2. IR1 (IrDA Infrared) Interface Port

The 3301570 comes with an integrated IrDA port which supports either a Serial Infrared (SIR) or an Amplitude Shift Keyed IR(ASKIR) interface.

PIN	DESCRIPTION	PIN	DESCRIPTION
1	VCC	2	NC
3	IR-RX	4	GND
5	IR-TX		



Figure 2-4

IR1 IrDA Interface Port

Table 2-5 IR1 IrDA Interface Port Pinouts

### 3. ATXCTL

ATX 5V standby power supply connector as a 3-pin header.

PIN	DESCRIPTION
1	5VSB
2	PS-ON-
3	GND



Figure 2-5 ATXCTL Control

Table 2-6 ATXCTL Control Pinouts

#### 4. FAN1

This is an auxiliary 3-pin fan connector with +12V source and a sensor pin.

PIN	DESCRIPTION	PIN	DESCRIPTION
1	GND	2	+12V
3	Sensor		



Figure 2-6

Fan1 Power Source


Table 2-7 Fan1 Connector Pinouts

## 5. IDE Connector

One IDE connector can connect to one IDE cable, and the single IDE cable can then connect to two IDE devices.

PIN	DESCRIPTION	PIN	DESCRIPTION
1	RESET#	2	GND
3	DATA 7	4	DATA 8
5	DATA 6	6	DATA 9
7	DATA 5	8	DATA 10
9	DATA 4	10	DATA 11
11	DATA 3	12	DATA 12
13	DATA 2	14	DATA 13
15	DATA 1	16	DATA 14
17	DATA 0	18	DATA 15
19	GND	20	(KEY)
21	DRQ	22	GND
23	IOW#	24	GND
25	IOR#	26	GND
27	CHRDY	28	GND
29	DACK	30	GND
31	INTERRUPT	32	N/C
33	SA1	34	P66DET
35	SA0	36	SA2
37	HDC CS0#	38	HDC CS1#
39	HDD ACTIVE#	40	GND

**Table 2-8 IDE Connector Pinouts**




**Figure 2-7 IDE Connector**

## 6. FDD (Floppy) Port

The FDD connector is used to connect a floppy cable while the other end of the cable connects to the FDD drive. The types of FDD drives supported are: 360KB, 720KB, 1.2MB, 1.44MB and 2.88MB. Please connect the red power connector wire to the pin1 position.

PIN	DESCRIPTION	PIN	DESCRIPTION
1	GND	2	RWCO-
3	GND	4	NC
5	NC	6	NC
7	GND	8	INDEX-
9	GND	10	MO-A
11	GND	12	DS-B
13	GND	14	DS-A
15	GND	16	MO-B
17	GND	18	DIR-
19	GND	20	STEP-
21	GND	22	WD-
23	GND	24	WGATE-
25	GND	26	TRKO-
27	GND	28	WP-
29	GND	30	RDATA-
31	GND	32	HEAD-
33	GND	34	DSKCHG-

**Table 2-9 FDD Port Pinouts**




**Figure 2-8 FDD Port**

**7. LPT1 Parallel Port**

LPT1 is an IEEE1284 compatible interface. Usually, the parallel port connects to a printer. This port is provided as a 26-pin flat cable connector.

PIN	DESCRIPTION	PIN	DESCRIPTION
1	STB-	2	PDR0
3	PDR1	4	PDR2
5	PDR3	6	PDR4
7	PDR5	8	PDR6
9	PDR7	10	ACK-
11	BUSY	12	PE
13	SLCT	14	AFD-
15	ERR-	16	INITP-
17	SLIN-	18	GND
19	GND	20	GND
21	GND	22	GND
23	GND	24	GND
25	GND	26	GND

**Table 2-10 LPT1 Parallel Port Pinouts**



**Figure 2-9 LPT1 Parallel Port**

## 8. DIO1 Digital I/O Header

This port allows connection of customer-defined general purpose I/Os controlled by the super I/O chip (Windbond 83627THF).

PIN	DESCRIPTION	PIN	DESCRIPTION
1	GND	2	PWR(+5V)
3	XOUT0	4	XOUT1
5	XOUT2	6	XOUT3
7	XIN0	8	XIN1
9	XIN2	10	XIN3

Table 2-11 DIO1 Digital I/O Header Pinouts




Figure 2-10 DIO1 Digital I/O Header

## 9. CN2 KB/MS Connector

This port connects to a PS/2 mouse or keyboard using a 6-pin-to-PS/2 adapter cable.

PIN	DESCRIPTION	PIN	DESCRIPTION
1	PWR(+5V)	2	MS_DATA
3	MS_CLK	4	MS_DATA
5	MS_CLK	6	GND

Table 2-12 CN2 KB/MS Connector Pinouts





Figure 2-11 CN2 KB/MS Connector

## 10. COM Ports

The 3301570 offers two high speed NS16C550 compatible UART's with 16-byte Read/Receive FIFO serial ports.

PIN	DESCRIPTION	PIN	DESCRIPTION
1	DCD-	2	SIN
3	SOUT	4	DTR-
5	GND	6	DSR-
7	RTS-	8	CTS-
9	RI	10	GND

**Table 2-13 COM Port Pinouts**




**Figure 2-12 COM Port**

## 11. Serial ATA Ports (SATA 1, 2, 3, and 4)

These four (4) connectors provide the connectivity to Serial ATA disk drives using the Serial ATA signal cables.

PIN	DESCRIPTION	PIN	DESCRIPTION
1	GND	2	STXP
3	STXN	4	GND
5	SRXN	6	SRXP
7	GND		

**Table 2-14 Serial ATA Port Pinouts**



**Figure 2-13 Serial ATA Port**



**NOTE:**

1. The Serial ATA has its limitations with the operating systems. Serial ATA is supported by Windows 2000 SP4, Windows XP SP1, Windows 2003, or later versions.
2. Older OSes, such as Windows 98SE or ME, do not support Serial ATA interface.


## 12. Audio01 Audio Port

This audio port connects to an externally mounted AC'97 audio kit.

Please refer to **Appendix E** for detailed information.

PIN	DESCRIPTION	PIN	DESCRIPTION
1	AC_SYNC	2	AC_CLK
3	AC_SDOOUT	4	PC_BEEP
5	AC_SDIN	6	AC_RST
7	PWR(+5V)	8	GND
9	PWR(+12V)	10	GND

**Table 2-15 Audio01 Audio Port Pinouts**



**Figure 2-14 Audio01 Audio Port**

### 13. USB (2.0) Ports

These three (3) connectors provide the connectivity to additional USB 2.0 devices

PIN	DESCRIPTION	PIN	DESCRIPTION
1	PWR(+5V)	2	GND
3	USBPA-	4	USBPB+
5	USBPA+	6	USBPB-
7	GND	8	PWR(+5V)

Table 2-16 USB (2.0) Port Pinouts




Figure 2-15 USB (2.0) Port

### 14. CPU\_FAN

This fan connector supports cooling fans using 350mA ~ 740mA or 1A ~ 2.2A at 12V power source. The 3301570 requires a cooling kit mounted on CPU to maintain the proper working condition. There is a “sense” pin in the fan connector, which transfers the fan’s sense signal to the system BIOS in order to recognize the fan speed. Please note that only some specific types of fans offer a rotation signal.

PIN	DESCRIPTION	PIN	DESCRIPTION
1	GND	2	+12V
3	Sensor	4	Control

Table 2-17 CPU\_FAN Pinouts



Figure 2-16 CPU\_FAN connector

## 2.2.2 Rear Panel Connectors




Figure 2-17 Rear Panel Connectors

### 1. PS/2 KB/MS Port.

This port is for a PS/2 mouse or keyboard.

PIN	DESCRIPTION	PIN	DESCRIPTION
1	Data	2	NC
3	GND	4	+5V
5	Clock	6	NC

Table 2-18 PS/2 KB/MS Port Pinouts




Figure 2-18 PS/2 KB/MS Port

**2. GbE Ethernet LAN (RJ-45) Port.**

This port allows Gigabit connection to Local Area Network (LAN) through a network hub. Refer to the table below for the LAN port LED indication.



**Figure 2-19 GbE Ethernet LAN (RJ-45) Port**

**LAN Port LED Indications**

SPEED LED		ACT/LINK LED	
Status	Description	Status	Description
OFF	10 Mbps connection	OFF	No link
ORANGE	100 Mbps connection	YELLOW	Linked
GREEN	1 Gbps connection	BLINKING	Date activity

**Table 2-19 LAN Port LED Indications**

3. Ethernet LAN port, same as above

**4. USB 2.0 Port**

This 4-pin Universal Serial Bus (USB) port is available for connecting USB 2.0 devices.

**5. VGA Port**

This 15-pin VGA port connects to a VGA monitor.

**Chapter**

**3**

# **Installation**

---

# 3.1 Considerations Prior to Installation

## Preparing Your CPU Board

The CPU board contains numerous delicate electronic circuits and components, which can become damaged as a result of electrostatic discharge (ESD). Thus, prior to installation, please follow the instructions below:

1. Please turn off the computer and unplug its power cord.
2. When handling the motherboard, avoid touching any metal leads or connectors.
3. It is best to wear an electrostatic discharge (ESD) cuff when handling electronic components (CPU, RAM).
4. Prior to installing the electronic components, please have these items on top of an antistatic pad or within an electrostatic shielding container.
5. Please verify that the power supply is switched off before unplugging the power supply connector from the motherboard.

## Installation Notices

1. Prior to installation, please do not remove the stickers on the CPU board. These stickers are required for warranty validation.
2. Prior to the installation of the CPU board or any hardware, please first carefully read the information in the provided manual.
3. Before using the product, please verify that all cables and power connectors are connected.
4. To prevent damage to the CPU board, please do not allow screws to come in contact with the PCB circuit, connector pins, or its components.
5. Please make sure there are no leftover screws or metal components placed on the CPU board or within the computer casing.
6. Please do not place the computer system on an uneven surface.
7. Turning on the computer power during the installation process can lead to damage to system components as well as physical harm to the user.
8. If you are uncertain about any installation steps or have a problem related to the use of the product, please consult a certified computer technician.

## Dual Channel Memory Configuration

The 3301570 is built on the Dual Channel Technology. The two memory channels handle memory-processing more efficiently by utilizing the theoretical bandwidth of the two modules. In this way, the system latencies and timing delays that frequently occurred with one memory module can be significantly improved.



### **WARNING!**

The DDR2 architecture is not compatible with DDR1 modules. If your system is installed with DDR1 modules, damage might occur and you will not be able to boot up your system.

---

## Memory Configuration Rules

At least one memory module should be installed, and installed in the “DDR II 1” slot. Each DIMM slot can support a memory module with the capacity up to 1GB.

The 3301570 provides four (4) DIMM sockets named as the following:

- z Channel A: DDR II 1.
- z Channel A: DDR II 2.
- z Channel B: DDR II 3.
- z Channel B: DDR II 4.

## Memory Selection


If you want to your system to benefit from the Dual Channel Technology, please note the following due to the limitations imposed on Intel chipset specifications.

1. Dual Channel mode will not be enabled if only one DDR2 memory module is installed.  
DIMMs must be installed in pairs
2. It is recommended to use memory modules of identical brand, size, chips, and speed.
3. DIMMs must use the same density memory chips
4. Both DIMMs must use the same DRAM bus width
5. Both DIMMs must be either single-sided or dual-sided.

## Immanent Hazards!

1. Please do not install three memory modules on three DIMM slots. Doing so might cause unpredictable failures.
2. If only one memory module is installed, install it to the first DIMM slot, i.e., DDRII 1.
3. Dual-channel DDR only works in the combinations listed below.

DDRII 1 (Ch A)	DDRII 2 (Ch A)	DDRII 3 (Ch B)	DDRII 4 (Ch B)	Total Capacity
256MB~1GB				256MB~1GB
256MB~1GB		256MB~1GB		512MB~2GB
	256MB~1GB		256MB~1GB	512MB~2GB
256MB~1GB	256MB~1GB	256MB~1GB	256MB~1GB	1GB~4GB



**Figure 3-1 DIMM Sockets**

## HT functionality requirements content

Enabling the functionality of Hyper-Threading Technology for your system requires meeting all of the requirements below on platform components:

- z CPU: An Intel® Pentium 4 Processor with HT Technology
- z Chipset: An Intel® Chipset that supports HT Technology (that has been met by the 3301570)
- z OS: An operation system that has optimizations for HT Technology

**WARNING!**

1. Never run the CPU board without an appropriate heatsink and cooler.
  2. Be sure to use CPU 12V power connector (PW) for the CPU power.
- 

## Unpacking Precautions

Some components on 3301570 are very sensitive to static electric charges and can be damaged by a sudden rush of power. To protect it from unintended damage, be sure to follow these precautions:


- z Ground yourself to remove any static charge before touching your 3301570. You can do so by using a grounded wrist strap at all times or by frequently touching any conducting materials that is connected to the ground.
- z Handle your 3301570 by its edges. Do not touch IC chips, leads or circuitry if not necessary.
- z Do not plug or unplug any connector or jumper while the power is on.
- z Do not place a PCB on top of an anti-static bag. Only the inside of the bag is safe from static discharge.

## 3.2 Jumper Settings




**NOTE:**

A jumper is a metal bridge that is used to close an electrical circuit. It consists of two metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To CLOSE/SHORT a jumper means connecting the pins of the jumper with the plastic clip and to OPEN a jumper means removing the plastic clip from a jumper.



**Figure 3-2 Jumper**

### JP1 (Clear CMOS)



**Figure 3-3 JP1 Jumper Location**

In case the CPU board fails to boot due to user's improper BIOS setting, this jumper can be used to clear the CMOS data and reset the system BIOS information. To clear the CMOS contents, shunt pins 2 and 3 for a few seconds, and then reinstall the jumper clip back to pins 1 and 2.

If the “CMOS Settings Wrong” message displays during the boot up process, you may then try to correct the fault by pressing the F1 to enter the CMOS Setup menu. You may then enter the correct CMOS setting, Load Optimal Defaults, or Load Failsafe Defaults. Save your changes and exit the CMOS Setup menu.

### JP1 Pin Configuration

JP1	CLEAR CMOS
1-2 closed	Normal (default)
2-3 closed	CLEAR CMOS

**Table 3-1 JP1 Pin Configuration**



#### **CAUTION!**

1. In normal condition, pins 1 and 2 must always stay in CLOSED condition.
  2. Power must be turned OFF before clearing CMOS data.
-

## External Switches and Indicators

### CN1 (PWR/HDD LED/SW/SPK/RST Pins)




Figure 3-4 CN1 Connector Location

### CN1 Pinouts

PIN	DESCRIPTION	PIN	DESCRIPTION
1	PWR LED+	2	PC_BEEP
3	PWR LED-	4	GND
5	PWR ON+	6	NC
7	PWR ON-	8	PWR(+5V)
9	HDD LED+	10	RESET+
11	HDD LED-	12	RESET-

Table 3-2 CN1 Pinouts

## 3.3 Installation

### CPU Installation

---



#### WARNING!

1. Please note that the installation instructions described in this manual should be carefully followed in order to avoid damage to the board components.
  2. Static-free installation environment: The 3301570 must be installed in a static-free environment to minimize the possibility of electrostatic discharge (ESD) damage. Use of an anti-static work pad or a grounded anti-static wrist strap is strongly recommended. To avoid damaging the CPU board components due to static electricity, never place your CPU board directly on a surface that is not static-free, e.g., a carpet.
  3. Always hold components by the edges and do not touch the ICs and connector pins.
  4. Do not remove a component from its anti-static bag before installation.
  5. Before you proceed with the installation process, check the CPU surface and check for bent pins on the socket.
  6. While installing the CPU, do not use force, serious damage to the CPU or CPU socket might occur.
- 

To install Intel 775-pin CPU onto your CPU board, follow the steps below:






Figure 3-5 Intel LGA775 Socket

- Step 1.** Remove the black protective cover by prying it off the load plate. The protective cover is used to protect the delicate pins on the LGA775 socket. Use your fingertip to peel it off from the edge of the shield where is marked by the “REMOVE” sign. Please refer to the diagram below for detail.



**Figure 3-6 LGA775 Socket Protective Cover**

- Step 2.** Disengage the load lever by pressing the lever down and slightly outward to clear the retention tab.
- Step 3.** Rotate the load lever to a fully open position.
- Step 4.** Rotate the load plate to the opposite direction.



**Figure 3-7 Load Lever and Load Plate at the Fully Open Position**

- Step 5.** Inspect the CPU socket for bent pins and make sure that the socket load plate and contacts are free of foreign material. Inspect socket contacts with one eye closed and from different angles. If debris should be found, remove them using the compressed

air.

**Step 6.** Insert the 775-pin CPU:


**6-1.** Hold the CPU by the LGA edges marked by back lines.

**6-2.** Orient the CPU with the IHS (Integrated Heat Sink) side facing upward.

**6-3.** Locate pin 1 and the two orientation notches on CPU.

**6-4.** Carefully match the two orientation notches on CPU with the alignment keys of the socket.

**6-5.** Carefully place the CPU into the socket with a gentle and vertical motion.



**Figure 3-8**      **Orienting CPU**

**Step 7.** Close the CPU socket. Close the load plate and engage the load lever by pushing it back to its original position. Secure the load lever under the retention tab on the side of CPU socket.



### **WARNING!**

**It is strongly recommended NOT to apply an Intel's original heatsink and cooler onto the 3301570!**

Because the CPU board is vertically mounted on a horizontal backplane, and Intel's heatsink does not come with a support bracket on the soldering side, the PCB may be bended by the weight of the cooling kit.

Cooling kit includes a support bracket that is combined with the heatsink mounted on the CPU to counterweigh and to balance the load on both sides of the PCB.

---

**Step 7.** Connect CPU 12V power source and the CPU fan connector after a heatsink is installed.

**Step 8.** Now you have completed the CPU installation process.

## Cooling Kit (CF-520) Installation



**Figure 3-9 Cooling Kit**

Cooling kit designed for socket 775 CPU.  
heatsink, a cooling fan, and a support bracket.

The cooling kit is comprised of a CPU




**NOTE:**

The heatsink comes with a sprayed layer of thermal paste. Make sure you do not accidentally wipe away the thermal paste while unpacking or installing the heatsink. Thermal paste between the CPU and the heatsink is important for optimum heat dissipation.

---

### Installation Steps:

- Step 1.** Place the heatsink onto the socket. Make sure that the CPU cable can be properly routed when the heatsink is installed.
- Step 2.** Align the heatsink so that its four (4) spring screw fasteners can pass through the through holes on PCB.
- Step 3.** From the other side of PCB, align the support bracket to the heatsink's screw threads that come through the PCB holes.



**Figure 3-10** Heatsink and the Support Bracket

- Step 4.** Use a cross-head screwdriver to tighten the four (4) fasteners on the heatsink to the holes on the support bracket. Screw the bolts in slightly, and then tighten each bolt a few turns at a time.
  
- Step 5.** Connect the fan cable on the heatsink to the CPU fan connector on the 3301570. Carefully route the cable and avoid heat generating chips and fan blades. The use of cable ties is recommended.
  
- Step 6.** You are done with heatsink installation.

## DIMM Installation

The 3301570 provides four (4) DIMM sockets for a maximum total memory module up to 4GB DDR SDRAM.

To install memory module, first make sure the two white clips on the DIMM socket are in the “open” position (the handles lean outward).

Verify the orientation of the module by checking the notch on the memory module. Slowly slide the DIMM module along the plastic guide on both ends of the socket, then press the DIMM module down into the socket, until you hear a “click” sound. This is when the two clips have automatically locked the module into the correction position of the DIMM socket. To remove the DIMM module, push both handles outward, and the memory module should be ejected by the mechanism in the socket.

## Connections to the Peripherals

The following cables are to facilitate connections to your peripheral devices. For more information on the locations of the connectors, please refer to Chapter 2. Cables not included in kit are user supplied items and should be separately purchased.

No.	Type
1	ATA 66/100 flat cable
2	SATA cables
1	SATA power cable
1	Keyboard/ PS2 mouse Y cable
1	ATX-12V cable
1	Parallel port & RS-232 cable
1	USB cable
1	FDD cable

**Table 3-3 Cables Included in Kit**

This page is intentionally left blank.

Chapter

4

# AMI BIOS Setup

---

## Introduction

This chapter discusses AMI's Setup program built into the ROM BIOS. The Setup program allows users to modify the basic system configuration. This special information is then stored in battery-backed RAM so that it retains the Setup information when the power is turned off.

## Starting Setup

The AMI BIOS is immediately activated when you first power on the computer. The BIOS reads the system information contained in the CMOS and begins the process of checking out the system configuration. When it finishes, the BIOS will seek an operating system on one of the disks and then launch and turn control over to the operating system.

While the BIOS is in control, the Setup program can be activated in one of two ways:

1. By pressing <Del> immediately after switching the system on, or
2. By pressing the <Del> key when the following message appears briefly at the bottom of the screen during the POST.

**Press DEL to enter SETUP.**

If the message disappears before you respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing the "RESET" button on the system case. You may also restart by simultaneously pressing <Ctrl>, <Alt>, and <Delete> keys.

## Using Setup

In general, you use the arrow keys to highlight items, press <Enter> to select, use the PageUp and PageDown keys to change entries, press <F1> for help and press <Esc> to quit. The following table provides more detail about how to navigate in the Setup program using the keyboard.

Key	Function
Up arrow	Move to previous item
Down arrow	Move to next item
Left arrow	Move to the item on the left hand side
Right arrow	Move to the item on the right hand side

Esc key	Main Menu – Quit and not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu -- Exit current page and return to Main Menu
Page Up key	Increase the numeric value or make changes
Page Dn key	Decrease the numeric value or make changes
F1 key	General help, only for Status Page Setup Menu and Option Page Setup Menu
F2 /F3 key	Change color from total 16 colors. F2 to select color forward.
F10 key	Save all the CMOS changes, only for Main Menu

**Table -1 BIOS Function Keys**

## Getting Help

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window press <Esc> or the **F1** key again.

If, after making and saving system changes with Setup, you discover that your computer no longer is able to boot, the AMI BIOS supports an override to the CMOS settings which resets your system to its defaults.

The best advice is to only alter settings which you thoroughly understand. To this end, we strongly recommend that you avoid making any changes to the chipset defaults. These defaults have been carefully chosen by both AMI and your systems manufacturer to provide the absolute maximum performance and reliability. Even a seemingly small change to the chipset setup has the potential for causing you to use the override.


## BIOS Menu Bar

The menu bar on top of the screen has the following main items:

<b>Main</b>	For changing the basic system configuration.
<b>Advanced</b>	For changing the advanced system settings.
<b>PCIPnP</b>	For changing the advanced PCI/PnP Settings
<b>Boot</b>	For changing the system boot configuration.
<b>Security</b>	Use this menu to set User and Supervisor Passwords.
<b>Chipset</b>	For changing the chipset setting.
<b>Exit</b>	For selecting the exit options and loading default settings.

## 4.1 Main

When you enter the BIOS Setup program, the Main menu screen appears giving you an overview of the basic system information.



### AMI BIOS

This item displays the auto-detected BIOS information.

### Processor

This item displays the auto-detected CPU specification.

### System Memory

This item displays the auto-detected system memory.

### System Time [xx:xx:xx]


This item allows you to set the system time.

### System Date [Day xx/xx/xxxx]

This item allows you to set the system date.


## 4.2 Advanced

The Advanced menu items allow you to change the settings for the CPU and other system devices.



## CPU Configuration

This menu contains items shown in the CPU-related information window that are automatically detected by BIOS.



### Max CPUID Value Limit

This item should be disabled for Windows XP.

Configuration options: [Disabled] [Enabled]


### Hyper-Threading Technology [Enabled]

This item allows you to enable or disable the processor Hyper-Threading Technology.

Configuration options: [Disabled] [Enabled]

## IDE Configuration

The items in this menu allow you to set or change the configurations for the IDE devices installed in the system. Select an item then press Enter if you wish to configure the item.



### ATA/IDE Configuration [Disable/Combined/Enhanced]

Disabled: Disable this function.

Compatible: You can use up to 6 HDDs on the motherboard; 4 for SATA and the other for PATA IDE.

Enhanced: The motherboard allows up to 6 HDDs to use. The Enhanced mode triggers one advanced option which allows you to configure your SATA drives into RAID volumes. The RAID configuration also requires Intel's software utilities installed on your operating system.

When set to the Enhanced mode, a different option for SATA drives, "Configure SATA as," will appear.

**NOTE:**

There are ways to access Intel's proprietary RAID configuration utility such as pressing the Ctrl+I keys together during POST. The access may vary and it is recommended to refer to **Appendix D** of this manual or Intel's documentation for more information.

**Legacy IDE Channels**

Available options are: [SATA Only] [PATA Pri, SATA Sec] [SATA Pri, PATA Sec] [PATA Only]

**Configure SATA as [IDE/RAID/AHCI]**

This option appears only when the ATA/IDE Configuration option is set to "Enhanced." Available options are: [IDE] [RAID] [AHCI]

IDE:	Operate as normal IDE device.
RAID:	Operate as member drives in RAID configuration(s).
AHCI:	Operate in this mode for enabling advanced performance and usability. This mode is supported only with Intel's ICH7R chipset.

**Configuration SATA Channels [Before PATA/Behind PATA]** Before

PATA: SATA become Primary & Secondary, PATA become Third.

Behind PATA: PATA become Primary, PATA become Secondary & Third.

**Primary and Secondary, Third IDE 0/1**

The values opposite the dimmed items (Device, Vendor, Size, LBA Mode, Block Mode, PIO Mode, Async DMA, Ultra DMA, and SMART monitoring) are auto-detected by BIOS and are not user-configurable. These items show N/A if no IDE device is installed in the system.

**Type [Auto]**

Selects the type of IDE drive. Setting to Auto allows automatic selection of the appropriate IDE device type. Select CDROM if you are specifically configuring a CD-ROM drive. Select ARMD (ATAPI Removable Media Device) if your device is either a ZIP, LS-120, or MO drive.  
Configuration options: [Not Installed] [Auto] [CDROM] [ARMD].

**LBA/Large Mode [Auto]**

Enables or disables the LBA mode. Setting to Auto enables the LBA mode if the device supports this mode, and if the device was not previously formatted with LBA mode disabled.  
Configuration options: [Disabled] [Auto]

### **Block (Multi-Sector Transfer) [Auto]**

Enables or disables data multi-sectors transfers. When set to Auto, the data transfer from and to the device occurs multiple sectors at a time if the device supports multi-sector transfer feature. When set to Disabled, the data transfer from and to the device occurs one sector at a time.

Configuration options: [Disabled] [Auto]

### **PIO Mode [Auto]**

Selects the PIO mode.

Configuration options: [Auto] [0] [1] [2] [3] [4]

### **DMA Mode [Auto]**

Selects the DMA mode.

Configuration options: [Auto] [SWDMA0] [SWDMA1] [SWDMA2] [MWDMA0] [MWDMA1] [MWDMA2] [UDMA0] [UDMA1] [UDMA2] [UDMA3] [UDMA4] [UDMA5]

### **SMART Monitoring [Auto]**

Sets the Smart Monitoring, Analysis, and Reporting Technology.

Configuration options: [Auto] [Disabled] [Enabled]

### **32Bit Data Transfer [Disabled]**

Enables or disables 32-bit data transfer.

Configuration options:[Disabled] [Enabled]

### **Hard Disk Write Protect**

This item allows you to disable/enable device write protection. This will be effective only if device is accessed through BIOS.

Configuration options: [Disabled] [Enabled]

### **IDE Detect Time Out (Sec)**

This item allows you to select the timeout value for detecting ATA/ATAPI devices.

Configuration options: [0] [5] [10] [15] [20] [25] [30] [35]

### **ATA(PI) 80Pin Cable Detection**

This item allows you to select the mechanism for detecting 80-pin ATA(PI) cables.

Configuration options: [Host & Device] [Host] [Device]

## Floppy Configuration

Sets the type of floppy drive installed.

Configuration options: [Disabled][360KB, 5.25 in.][1.2MB, 5.25 in.][720KB, 3.5 in.] [1.44MB, 3.5 in.] [2.88MB, 3.5in.]

BIOS SETUP UTILITY	
Advanced	
<b>Floppy Configuration</b>	
Floppy A	[1.44 MB 3½"]
Floppy B	[Disabled]
Select the type of floppy drive connected to the system.	
↔ Select Screen ↑↓ Select Item +- Change Option F1 General Help F10 Save and Exit ESC Exit	
v02.58 (C) Copyright 1985-2004, American Megatrends, Inc.	

## Super IO Configuration

### On Board Floppy Controller [Enabled]

Allows you to enable or disable the floppy disk controller.

Configuration options: [Disabled] [ Enabled]

### Serial Port1 Address [3F8/IRQ4]

Allows you to select the Serial Port1 base address.

Configuration options: [Disabled] [3F8/IRQ4] [3E8/IRQ4] [2E8/IRQ3]

### Serial Port2 Address [2F8/IRQ3]

Allows you to select the Serial Port2 base address.

Configuration options: [Disabled] [2F8/IRQ3] [3E8/IRQ4] [2E8/IRQ3]

### Parallel Port Address [378]

Allows you to select the Parallel Port base addresses.

Configuration options: [Disabled] [378] [278] [3BC]

## Parallel Port Mode [Normal]

Allows you to select the Parallel Port mode.

Configuration options: [Normal] [Bi-directional] [EPP] [ECP] [ECP & EPP]

## Parallel Port IRQ [IRQ7]

Configuration options: [IRQ5] [IRQ7]

BIOS SETUP UTILITY		
Advanced		
OnBoard Floppy Controller	[Enabled]	Allows BIOS to Enable or Disable Floppy Controller.
Serial Port1 Address	[3F8/IRQ4]	
Serial Port2 Address	[2F8/IRQ3]	
Serial Port2 Mode	[Normal]	
Parallel Port Address	[378]	
Parallel Port Mode	[Normal]	
Parallel Port IRQ	[IRQ7]	
		↔ Select Screen
		↑↓ Select Item
		+ - Change Option
		F1 General Help
		F10 Save and Exit
		ESC Exit

u02.58 (C) Copyright 1985-2004, American Megatrends, Inc.

## Hardware Health Configuration

BIOS SETUP UTILITY	
Advanced	
Hardware Health Configuration	Options
CPU Fan Target Temperature	[Disabled]
System Temperature	:39°C/102°F
CPU Temperature	:45°C/113°F
System Fan Speed	:N/A
CPU Fan Speed	:2636 RPM
Ucore	:1.290 V
+12V	:11.706 V
+3.3V	:3.354 V
AVCC	:5.000 V
+1.8V	:1.806 V
+5USB	:5.080 V
VBAT	:3.322 V
	Disabled 40°C/104°F 50°C/122°F 60°C/140°F 70°C/158°F
	↔ Select Screen ↑↓ Select Item +- Change Option F1 General Help F10 Save and Exit ESC Exit
v02.58 (C) Copyright 1985-2004, American Megatrends, Inc.	


### CPU Fan Target Temperature

This item provides you several preset values for setting the high temperature threshold. With a set threshold, a dual-speed fan with temperature sensor will operate at a low rotation speed when the detected temperature is within the safe range.

Available options are: [Disabled] [40°C/104°F] [50°C/122°F] [60°C/140°F] [70°C/158°F]

## ACPI Configuration

Allows you to change the settings for the Advanced Power Management (APM). Select an item then press Enter to display the configuration options.



### General ACPI Configuration

Allows you to select the ACPI state to be used for system suspend.

Configuration options: [S1 (POS)]

Configuration options: [S3 (STR)]

### Advanced ACPI Configuration

Use this section to configure additional ACPI options.

#### ACPI 2.0 Features

Enables RSDP pointers to 64-bit Fixed System Description Tables.

Configuration options: [Yes] [No]

#### ACPI APIC support

Includes ACPI APIC table pointer to RSDT pointer list.

Configuration options: [Enabled] [Disabled]

**AMI OEMB table**

Includes OEMB table pointer to R(X)SDT pointer lists

Configuration options:    [Enabled] [Disabled]

**Headless mode**

Enables or disables headless operation mode through ACPI.

Configuration options:    [Enabled] [Disabled]

**Chipset ACPI Configuration**

Use this section to configure Chipset ACPI related configuration options.

**Energy Lake Feaure**

Configuration options:    [Enabled] [Disabled]

**APIC ACIP SCI IRQ**

Configuration options:    [Enabled] [Disabled]

**APM Configuration**



**Power Management/APM [Enabled]**

Allows you to enable or disable the Advanced Power Management (APM) feature. Configuration options: [Disabled] [Enabled]

**Video Power Down Mode [Disabled]**

Allows the system to power down video in Suspend or Standby mode. Configuration options: [Disabled] [Suspend]

**Hard Disk Power Down Mode [Disabled]**

Allows the system to power down hard disk in Suspend or Standby Mode. Configuration options: [Disabled] [Suspend]

**Suspend Time Out [Disabled]**

Allows the system to suspend the operation of certain components in the specified time. Configuration options: [Disabled] [1 Min] [2 Min] [4 Min] [8 Min] [10 Min] [20 Min] [30 Min] [40 Min] [50 Min] [60 Min]

**Keyboard & PS/2 Mouse [Monitor]**

Allows the system to monitor KBC Ports 60/6.

Configuration options: [Disabled] [Monitor]

### **Power Button Mode [On/Off]**

Allows the system to go into On/Off mode or suspend mode when the power button is pressed.  
Configuration options: [On/Off] [Suspend]

## **Advanced Resume Event Controls**

### **Restore on AC Power Loss [Last State]**

When set to Power Off, the system goes into off state after an AC power loss. When set to Power On, the system goes on after an AC power loss.  
When set to Last State, the system goes into either off or on state  
Whatever was the system state before the AC power loss.  
Configuration options: [Power Off] [Power On] [Last State]

### **Resume On Ring [Disabled]**

Allows you to enable or disable RI to generate a wake event.  
Configuration options: [Disabled] [Enabled]

### **Resume On LAN [Disabled]**

Allows you to enable or disable LAN GPI to generate a wake event.  
Configuration options: [Disabled] [Enabled]

### **Resume On PME# [Disabled]**

Allows you to enable or disable PCI PME# to generate a wake event.  
Configuration options: [Disabled] [Enabled]

### **Resume On RTC Alarm [Disabled]**

Allows you to enable or disable RTC to generate a wake event. When this item is set to Enabled, the items RTC Alarm Date, RTC Alarm Hour, RTC Alarm Minute, and RTC Alarm Second appear with set values.  
Configuration options: [Disabled] [Enabled]

## MPS Configuration

Configure the Multi-Processor table

### MPS Revision [1.4]

Configuration options: [1.1] [1.4]

## Remote Access Configuration

Configure the Remote Access

### Remote Access [Disabled]

Configuration options: [Disabled] [Enabled]

## USB Configuration

The items in this menu allow you to change the USB-related features. Select an item then press Enter to display the configuration options.

### USB Function [8 USB Ports]

Allows you to set the number of USB ports to activate.

Configuration options: [Disabled] [2 USB Ports] [4 USB Ports] [6 USB Ports] [8 USB Ports]

### USB 2.0 Controller [Enabled]

Allows you to enable or disable the USB 2.0 controller.

Configuration options: [Disabled] [Enabled]

### Legacy USB Support [Enable]

Enable support for legacy USB.

Configuration options: [Auto] [Disabled] [Enabled]

### USB2.0 Controller Mode [Hi Speed]

This item configures the mode of USB 2.0 controller. It won't appear if USB 2.0 controller is disabled. This item configures the USB 2.0 controller in HiSpeed (480Mbps) or FullSpeed (12Mbps)

### BIOS EHCI Hand-Off [Enabled] [Disabled]


This is a workaround for OSES without EHCI hand-off support. The EHCI ownership change

should claim by EHCI driver.

BIOS SETUP UTILITY	
Advanced	
<b>USB Configuration</b> <hr/> Module Version - 2.24.0-11.4 USB Devices Enabled : None  Legacy USB Support            [Enabled] USB 2.0 Controller Mode       [HiSpeed] BIOS EHCI Hand-Off           [Enabled]	Configures the USB 2.0 controller in HiSpeed (480Mbps) or FullSpeed (12Mbps) .     ↔ Select Screen ↑↓ Select Item +- Change Option F1 General Help F10 Save and Exit ESC Exit
v02.58 (C) Copyright 1985-2004, American Megatrends, Inc.	

## PCIPnP

The PCIPnP menu items allow you to change the advanced PCI/PnP options. Select an item then press Enter to display the sub-menu.



### Clear NVRAM

Clear NVRAM during system boot

#### Clear NVRAM [No]

Configuration options: [No] [Yes]

### Plug & Play O/S

NO: lets the BIOS configure all the devices in the system.

YES: lets the operating system configure Plug and Play (PnP) devices not required for boot if your system has a Plug and Play operating system.

#### Plug & Play O/S [No]

Configuration options: [No] [Yes]

**PCI Latency Timer**

Value in units of PCI clocks for PCI device latency timer register

**PCI Latency Timer [64]**

Configuration options: [32] [64] [96] [128] [160] [192] [224] [248]

**Allocate IRQ to PCI VGA**

NO: Does not assign IRQ to PCI VGA card even if card requests an IRQ

YES: Assigns IRQ to PCI VGA card if card requests IRQ

**Allocate IRQ to PCI VGA [Yes]**

Configuration options: [No] [Yes]

**Palette Snooping**

Enabled: informs the PCI devices that an ISA graphics device is installed in the system so the card will function correctly.

**Palette Snooping [Disabled]**

Configuration options: [Disabled] [Enabled]

**PCI IDE BusMaster**

Enabled: BIOS uses PCI busmastering for reading/writing to IDE drives.

**PCI IDE BusMaster [Disabled]**

Configuration options: [Disabled] [Enabled]

**OffBoard PCI/ISA IDE Card**

Some PCI IDE cards may require this to be set to the PCI slot number that is holding the card.

**OffBoard PCI/ISA IDE Card [Auto]**

Configuration options: [Auto] [PCI Slot1] [PCI Slot2] [PCI Slot3] [PCI Slot4] [PCI Slot5] [PCI Slot6]

**IRQ#**

Available: Specified IRQ is available to be used by PCI/PnP devices.

Reserved: Specified IRQ is reserved for use by Legacy ISA devices.

## IRQ [Available]

Configuration options: [Available] [Reserved]

## DMA Channel#

Available: Specified DMA is available to be used by PCI/PnP devices.

Reserved: Specified DMA is reserved for use by Legacy ISA devices.

## DMA [Available]

Configuration options: [Available] [Reserved]

## Reserved Memory Size

Size of memory block to reserve for legacy ISA devices

## Reserved Memory Size [Disabled]

Configuration options: [Disabled] [16K] [32K] [64K]

BIOS SETUP UTILITY		
Main	Advanced	PCIPnP
OffBoard PCI/ISA IDE Card	[Auto]	▲
IRQ3	[Available]	
IRQ4	[Available]	
IRQ5	[Available]	
IRQ7	[Available]	
IRQ9	[Available]	
IRQ10	[Available]	
IRQ11	[Available]	
IRQ14	[Available]	
IRQ15	[Available]	
DMA Channel 0	[Available]	↔
DMA Channel 1	[Available]	↑↓
DMA Channel 3	[Available]	+ -
DMA Channel 5	[Available]	F1
DMA Channel 6	[Available]	F10
DMA Channel 7	[Available]	ESC
Reserved Memory Size	[Disabled]	▼

Size of memory block to reserve for legacy ISA devices.

↔ Select Screen  
 ↑↓ Select Item  
 + - Change Option  
 F1 General Help  
 F10 Save and Exit  
 ESC Exit

v02.5B (C) Copyright 1985-2004, American Megatrends, Inc.

## Boot

The Boot menu items allow you to change the system boot options. Select an item then press Enter to display the sub-menu.

BIOS SETUP UTILITY						
Main	Advanced	PCIPnP	Boot	Security	Chipset	Exit
<b>Boot Settings</b> <hr/> ▶ Boot Settings Configuration  ▶ Boot Device Priority ▶ Removable Drives			Configure Settings during System Boot.          ↔ Select Screen ↑↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit			
v02.58 (C)Copyright 1985-2004, American Megatrends, Inc.						

BIOS SETUP UTILITY		
Boot		
<b>Boot Settings Configuration</b> <hr/> Quick Boot [Enabled] Boot From LAN Support [Disabled] Quiet Boot [Disabled] AddOn ROM Display Mode [Force BIOS] Bootup Num-Lock [On] PS/2 Mouse Support [Enabled] Wait For 'F1' If Error [Enabled] Hit 'DEL' Message Display [Enabled] Interrupt 19 Capture [Disabled]		Allows BIOS to skip certain tests while booting. This will decrease the time needed to boot the system.          ↔ Select Screen ↑↓ Select Item +- Change Option F1 General Help F10 Save and Exit ESC Exit
v02.58 (C)Copyright 1985-2004, American Megatrends, Inc.		

## Boot Settings Configuration

### Quick Boot [Enabled]

Enabling this item allows BIOS to skip some power on self tests (POST) while booting to decrease the time needed to boot the system. When set to [Disabled], BIOS performs all the POST items.

Configuration options: [Disabled] [Enabled]

### Boot From LAN Support [Enabled]

Disable/Enable Boot from LAN support

Configuration options: [Disabled] [Enabled]

### Quiet Boot [Disabled]

This allows you to enable or disable the full screen logo display feature.

Configuration options: [Disabled] [Enabled]

### Add On ROM Display Mode [Force BIOS]

Sets the display mode for option ROM.

Configuration options: [Force BIOS] [Keep Current]

### Bootup Num-Lock [On]

Allows you to select the power-on state for the NumLock.

Configuration options: [Off] [On]

### PS/2 Mouse Support [Enabled]

Select support for PS/2 mouse.

Configuration options: [Disabled] [Enabled]

### Wait For 'F1' If Error [Enabled]

Wait for F1 key to be pressed if error occurs.

Configuration options: [Disabled] [Enabled]

### Hit 'DEL' Message Display [Enabled]

Displays "Press DEL to run Setup" in POST.

Configuration options: [Disabled] [Enabled]

### Interrupt 19 Capture [Enabled]

Enabled: Allows option ROMs to trap interrupt 19.

Configuration options: [Disabled] [Enabled]

## Boot Device Priority

### 1<sup>st</sup> Boot Device [HDD: xxx-xxxxx]

Specifies the boot sequence from the available devices. A device enclosed in parenthesis

has been disabled in the corresponding type menu.  
Configuration options: displayed in a pull-down list.

## **Hard Disk Drives**

### **1<sup>st</sup> Drive [HDD: xxx-xxxxx]**

Specifies the boot sequence from the available devices.  
Configuration options: displayed in a pull-down list.


## **Removable Drives**

### **1<sup>st</sup> Drive [HDD: xxx-xxxxx]**

Specifies the boot sequence from the available devices.  
Configuration options: displayed in a pull-down list.

## Security

The Security menu items allow you to change the system security settings. Select an item then press Enter to display the configuration options.



### Change Supervisor Password

Select this item to set or change the supervisor password. The Supervisor Password item on top of the screen shows the default Not Installed. After you have set a password, this item shows Installed.

### Change User Password


Select this item to set or change the user password. The User Password item on top of the screen shows the default Not Installed. After you have set a password, this item shows Installed.

### Boot Sector Virus Protection [Disabled]

Allows you to enable or disable the boot sector virus protection. Configuration options: [Disabled] [Enabled]

## Chipset

The Chipset menu items allow you to change the advanced chipset settings. Select an item then press Enter to display the sub-menu.



### North Bridge Configuration

#### Configure DRAM Timing by SPD [Enabled]

When this item is enabled, the DRAM timing parameters are set according to the DRAM SPD (Serial Presence Detect). When disabled, you can manually set the DRAM timing parameters through the DRAM sub-items.

Configuration options: [Disabled] [Enabled]

#### Initiate Graphic Adapter [PCI/IGD]

Allows selection of the graphics controller to use as primary boot device.

Configuration options: [IGD] [PCI/IGD] [PCI/PEG] [PEG/IGD] [PEG/PCI]

#### Internal Graphics Mode Select [Enable, 8MB]

Select the amount of system memory used by the internal graphics device.

Configuration options: [Enable, 1MB] [Enable, 4MB] [Enable, 8MB] [Enable, 16MB] [Enable, 32MB]

### **PEG Port Configuration [Auto] [Disabled]**

Allows you to enable or disable the PEG port.  
Configuration options: [Auto] [Disabled]

### **PEG Force x1 [Enabled] [Disabled]**

Allows you to enable or disable the PEG Force x1 functionality.  
Configuration options: [Enabled] [Disabled]

## **South Bridge Chipset Configuration**

### **Onboard LAN1 Controller [Enabled]**

Enable or Disable the onboard LAN.  
Configuration options: [Disabled] [Enabled]

### **Onboard LAN2 Controller [Enabled]**

Enable or Disable the onboard LAN.  
Configuration options: [Disabled] [Enabled]

### **USB Functions [8 USB Ports]**

Define how many USB ports you wish to enable for your system.  
Configuration options: [Disabled] [2 USB Ports] [4 USB Ports] [6 USB Ports] [8 USB Ports]

### **USB 2.0 [Enabled]**

Enable or Disable USB 2.0 support.  
Configuration options: [Enabled] [Disabled]

### **Audio Controller [Auto]**

Specify which audio specification you want to apply for your system.  
Configuration options: [Auto] [Azalia] [AC'97 Audio and Modem] [All Disabled]

### **SMBUS Controller [Enabled]**

Enable or Disable SMBUS.  
Configuration options: [Enabled] [Disabled]

### **Restore on AC Power Loss [Last State]**

When set to Power Off, the system goes into off state after an AC power loss. When set to Power On, the system goes on after an AC power loss.  
When set to Last State, the system goes into either off or on state  
Whatever was the system state before the AC power loss.  
Configuration options: [Power Off] [Power On] [Last State]

## PCIE Ports Configuration

### PCIE Port# [Auto]

This item allows you to manually enable, disable, or let the hardware decide the PCIE bus configuration.

Configuration options: [Auto] [Enabled] [Disabled]


### PCIE High Priority Port [Auto]

This item allows you to manually determine which PCIE port has the highest priority.

Configuration options: [Disabled] [Port 0] [Port 1] [Port 2] [Port 3] [Port 4] [Port 5]

## Exit

The Exit menu items allow you to load the optimal or failsafe default values for the BIOS items, and save or discard your changes to the BIOS items.



### Save Changes and Exit

Once you are finished making your selections, choose this option from the Exit menu to ensure the values you selected are saved to the CMOS RAM. The CMOS RAM is sustained by an onboard backup battery and stays on even when the PC is turned off. When you select this option, a confirmation window appears.

Select [Yes] to save changes and exit.

### Discard Changes and Exit

Select this option only if you do not want to save the changes that you made to the Setup program. If you made changes to fields other than system date, system time, and password, the BIOS asks for a confirmation before exiting.

### Discard Changes

This option allows you to discard the selections you made and restore the previously saved values. After selecting this option, a confirmation appears. Select [Yes] to discard any changes and load the previously saved values.

### Load Optimal Defaults

This option allows you to load optimal default values for each of the parameters on the Setup menus. **F9 key can be used for this operation.**

**Load Failsafe Defaults**

This option allows you to load failsafe default values for each of the parameters on the Setup menus. **F8 key can be used for this operation.**

This page is intentionally left blank

Chapter

**5**

# **USB 2.0 Configuration**

---

## 5.1 Introduction

The 3301570 is designed with Intel ICH7R that supports both USB1.1 and USB 2.0 high-speed transmission. It still remains the compatibility with today's USB device. High-speed USB 2.0 provides data transfer up to 480Mb/s which is 40 times faster than USB 1.1. It is ideal for today's speed-demanding I/O peripherals.

- z Provides data transmission rate up to 480Mb/s
- z Offers 40 times greater bandwidth than USB 1.1
- z Offers complete compatibility with current USB device

## 5.2 Installation


---



### NOTE:

1. Before installing the LAN drivers, make sure the CSI utility has been installed in your system. See **Chapter 4** for information on installing the CSI utility.
  2. USB 2.0 driver is not available for Windows 98SE/ME from product driver CD. Under these operating systems, the USB device will operate at USB 1.1 speeds.
- 


- Step 1.** From Windows XP, select Start and click on Control Panel. In the window of Control Panel, click on icon System.



**Step 2.** Choose the option "Hardware", and then click on "Device Manager."



**Step 3.** In Device Manager, choose "USB Controller" and then double click.




**Step 4.** Choose the option "Driver" and then click on "Update Driver".



- Step 5.** In Hardware Update Wizard, choose "Install from a list or specific location (Advanced)" and then click on " Next."




- Step 6.** Tick "Include this location in the search" and click "Next".



## 3301570 User Manual

- Step 7.** In the following windows, please specify the location "D:\USB20\Intel\WinXP" and then click on "OK".



- Step 8.** In the following window, please click on "Finish" to complete USB driver installation.



Appendix

**A**

# Watchdog Timer

---



## NOTE:

The following discussion applies to DOS environment. It is recommended you contact GAI support or visit our website for specific drivers for more sophisticated operating systems, e.g., Windows and Linux.

The Watchdog Timer is provided to ensure that standalone systems can always recover from catastrophic conditions that cause the CPU to crash. This condition may have occurred by external EMI or a software bug. When the CPU stops working correctly, Watchdog Timer will either perform a hardware reset (cold boot) or a Non-Maskable Interrupt (NMI) to bring the system back to a known state.

A BIOS function call (INT 15H) is used to control the Watchdog Timer:

### INT 15H:

AH – 6FH Sub-function:	
AL – 2:	Sets the Watchdog Timer's period.
BL:	Time-out value (Its unit-second is dependent on the item "Watchdog Timer unit select" in CMOS setup).

**Table A-1 AH-6FH Sub-function**

You have to call sub-function 2 to set the time-out period of Watchdog Timer first. If the time-out value is not zero, the Watchdog Timer will start counting down. While the timer value reaches zero, the system will reset. To ensure that this reset condition does not occur, calling sub-function 2 must periodically refresh the Watchdog Timer. However, the Watchdog timer will be disabled if you set the time-out value to be zero.

A tolerance of at least 10% must be maintained to avoid unknown routines within the operating system (DOS), such as disk I/O that can be very time-consuming.

**NOTE:**

When exiting a program it is necessary to disable the Watchdog Timer, otherwise the system will reset.

---

Example program:

```

; INITIAL TIMER PERIOD COUNTER
;
W_LOOP:

    MOV     AX, 6F02H    ;setting the time-out value
    MOV     BL, 30      ;time-out value is 48 seconds
    INT     15H

;
; ADD YOUR APPLICATION PROGRAM HERE
;
    CMP     EXIT_AP, 1    ;is your application over?
    JNE     W_LOOP      ;No, restart your application

    MOV     AX, 6F02H    ;disable Watchdog Timer
    MOV     BL, 0        ;
    INT     15H

;
; EXIT ;

```

This page is intentionally left blank

Appendix

**B**

# Address Mapping

---

**B.1 IO Address Map**

I/O address Range	Description
000-01F	DMA Controller
020-021	Interrupt Controller
040-043	System time
060-06F	Keyboard Controller
070-07F	System CMOS/Real time Clock
080-09F	DMA Controller
0A0-0A1	Interrupt Controller
0C0-0DF	DMA Controller
0F0-0FF	Numeric data processor
1F0-1F7	Primary IDE Channel
2F8-2FF	Serial Port 2 (COM2)
378-37F	Parallel Printer Port 1 (LPT1)
3B0-3BB	Intel(R) 82915 Graphics Controller
3C0-3DF	Intel(R) 82915 Graphics Controller
3F6-3F6	Primary IDE Channel
3F7-3F7	Standard floppy disk controller
3F8-3FF	Serial Port 1 (COM1)

**Table -1 IO Address Map**

**B.2 1st MB Memory Address Map**

Memory address	Description
00000-9FFFF	System memory
A0000-BFFFF	VGA buffer
F0000-FFFFFF	System BIOS
1000000-	Extend BIOS

**Table -2 1<sup>st</sup> MB Memory Address Map**

### B.3 IRQ Mapping Table

IRQ0	System Timer	IRQ8	RTC clock
IRQ1	Keyboard	IRQ9	ACPI
IRQ2	Available	IRQ10	LAN
IRQ3	COM2	IRQ11	LAN/USB2.0/SATA
IRQ4	COM1	IRQ12	PS/2 mouse
IRQ5	SMBus Controller	IRQ13	FPU
IRQ6	FDC	IRQ14	Primary IDE
IRQ7	Available	IRQ15	Secondary IDE

**Table -3 IRQ Mapping Table**

### B.4 DMA Channel Assignments

Channel	Function
0	Available
1	Available
2	Floppy disk (8-bit transfer)
3	Available
4	Cascade for DMA controller 1
5	Available
6	Available
7	Available

**Table -4 DMA Channel Assignments**

This page is intentionally left blank

Appendix

**C**

# **SDVO Connectivity**


---

# 3301570 User Manual

The graphics core onboard the 3301570 provides responsive graphics performance and seamless video playback with the support for ADD2 interface card. Combined with an Intel Graphics Media Accelerator Driver, an ADD2 card can be used to display system output to a television, digital display, or simultaneously to a monitor and digital display.

A second independent display can be installed on the PCI Express x16 slot of the backplane and the SDVO signals travel through a separately connected cable to the backplane and then the PCI Express x16 interface. Here GAI's backplane will be used as an example.

Locate the CN2 connector on the backplane and connect CN2 to the CPU board's SDVO1 connector. The location of the SDVO1 connector is shown on the next page.






Figure CT-2 SDVO Connector

This page is intentionally left blank

Appendix

**D**

# Intel<sup>®</sup> ICH7R SATA RAID

---


## Introduction

The SATA RAID function that came with the southbridge ICH7R that allows you to combine four SATA-II disk drives into RAID volume configurations. RAID configurations help you to increase disk access speed (RAID0), or to withstand a single disk drive failure (RAID1 or RAID5) and thus protect your precious data.


Intel's Matrix Storage is integrated with the system BIOS on system boards with a supported Intel chipset. The Intel Matrix RAID option provides BIOS and RAID volume management utilities for different OSes. Please use <Ctrl> + <I> keys to enter the "Intel(R) Matrix Storage Manager option ROM" status screen, which should appear early in system boot-up, during the POST (Power-On Self Test).

Following are the main features provided by the ICH7R RAID functionalities:


1. RAID0 (Striping),




## 2. RAID1 (Mirroring),



## 3. RAID5 (Block Interleaved Distributed Parity),



4. RAID10 (A Stripe of Mirrors)



5. Intel Matrix Storage Manager utility



**NOTE:**

You must properly configure the associated BIOS setting before the Ctrl+I key combination can take effect. Please refer to **Chapter 4 AMI BIOS Setup**, the discussions of **ATA/IDE configuration** Æ **ATA/IDE Configuration to [Enhanced]** Æ **Configure SATA as**, for more details.



## CAUTION!


A configured RAID volume (which may consist of multiple hard drives) appears to an operating system as a contingent storage space. Your operating system will not be able to distinguish the physical disk drives contained in a RAID configuration.

### Precautions:

1. One key benefit a RAID configuration brings you is that a single hard drive can fail within a RAID array without damaging your data. With RAID1, RAID10, and RAID5 arrays, you can replace a failed drive and restore your RAID configuration.

***However, if you replace the wrong drive when you are trying to remove a failed one, irrecoverable data loss will occur!*** It is therefore strongly recommended to mark the physical connections of all of your SATA disk drives. If a drive member of a RAID array should fail, you will then be able to correctly locate a failed drive.

### PCIE-9450 CPU Card



For example, you may specify the drive locations by attaching stickers to the drive bays. You need a reminder if the cabling do not match the physical locations of hard drives.

2. It is also crucial that you do not accidentally disconnect the SATA drive cables. Carefully route your cables within the chassis to avoid system down time.

## BIOS Configuration

The Intel Matrix Storage Manager option ROM is integrated with system BIOS. Use the combination of the <Ctrl> + <I> keys to enter the Intel RAID for Serial ATA" configuration screen, which should appear early in system boot-up during the POST stage.

1. Creating, Deleting and Resetting RAID Volumes:

The Serial ATA RAID volume may be configured using the RAID Configuration utility stored within the Intel RAID Option ROM. During the Power-On Self Test (POST), the following message will appear for a few seconds:

```
Intel(R) Matrix Storage Manager option ROM v5.0.0.1032 ICH7R wRAID5
Copyright(C) 2003-05 Intel Corporation. All Rights Reserved.

RAID Volumes
None Defined.

RAID Volumes:
None defined.

Physical Disks:
Port Drive Model Serial # Size Type/Status(Vol ID)
0 WDC WD800JD-00LS WD-WMAM9F815458 # 74.5GB Non-RAID Disk
1 WDC WD800JD-00LS WD-WMAM9F815458 # 74.5GB Non-RAID Disk
2 WDC WD800JD-00LS WD-WMAM9F815458 # 74.5GB Non-RAID Disk
3 WDC WD800JD-00LS WD-WMAM9F815458 # 74.5GB Non-RAID Disk

Press <CTRL-I> to enter Configuration Utility.
```

After the above message shows, press <Ctrl> and <I> keys simultaneously to enter the RAID Configuration Utility.

**NOTE:**

The RAID configuration process will destroy your data if apply used drives in your system. The following procedure is therefore only recommended for a new system or if you have backed up your data elsewhere and want to re-install your OS.

The main configuration screen should appear after pressing the <Ctrl> and <I> keys:

```

Intel(R) Matrix Storage Manager option ROM v5.0.0.1032 ICH7R wRAID5
Copyright(C) 2003-05 Intel Corporation. All Rights Reserved.

[ MAIN MENU ]
1. Create RAID Volume
2. Delete RAID Volume
3. Reset Disks to Non-RAID
4. Exit

[ DISK/VOLUME INFORMATION ]

RAID Volumes:
None defined.

Physical Disks:
Port Drive Model          Serial #          Size    Type/Status(Vol ID)
0   WDC WD800JD-00LS      WD-WMAM9F815458 # 74.5GB Non-RAID Disk
1   WDC WD800JD-00LS      WD-WMAM9F815458 # 74.5GB Non-RAID Disk
2   WDC WD800JD-00LS      WD-WMAM9F815458 # 74.5GB Non-RAID Disk
3   WDC WD800JD-00LS      WD-WMAM9F815458 # 74.5GB Non-RAID Disk

```


## 1-1. Create a RAID Volume




### WARNING!

If you create a RAID volume out of used drives (drives that have data), all data on the selected drives will be erased. Make sure you have moved or backed up the data if you want to create a volume out of the used drives.


- Step 1.** Use the arrow keys to select “Create RAID Volume” and press <Enter> to proceed.
- Step 2.** When prompted by the “CREATE VOLUME MENU” screen, specify a RAID volume name, e.g., RD resource, and then press the <TAB> or <Enter> key to move on to the next field.



- Step 3.** Use the <Up> and <Down> arrow keys to select the RAID level that will be applied to your selected group of drives. Note that the disks selectable and the stripe size options may be disabled because, for example, a RAID1 array is not configured using the striping method. Press <Enter> to proceed.



**Step 4.** Press <Enter> to display a drive selection screen.



- Step 5.** Use the <Space> key to select the disk drives to be included in the RAID volume, and then press <Enter> to finish the selection.




**Step 6.** Press the <TAB> key to move to the “Stripe Size” field, and then use the <Up> or <Down> arrow keys to change the stripe size value. Press <Enter> to end the selection. Note that if an inappropriate value is selected, the read/write performance of your array may be affected.


16KB: Best for sequential transfers

64KB: Good general purpose stripe size

128KB: Best performance for most desktops and workstations



**Step 7.** Select the capacity of the volume in the “Capacity” field. The default is the maximum volume capacity of the selected hard drives. Usually you do not have to change the usable capacity of the array.




## NOTE:


If you want to create two volumes out of the same group of disk drives, this default size (maximum) needs to be reduced. Type in a new size for the current volume. The second volume will automatically span the remainder of the same group of disk drives.

---

**Step 8.** A confirm message should appear requiring you to confirm the creation. Press <Y> to continue.




**Step 9.** When the following screen appears showing the information of configured arrays, then the creation is finished.




## 1-2. Delete a RAID Volume

Here you can delete the RAID volume, but please be noted that all data on RAID drives will be lost.

- Step 1.** Select option 2 **Delete RAID Volume** from the main menu window and press <Enter> key to select a RAID volume for deletion. The following window will appear:



**Step 2.** Select the volume and press <Delete> key to delete the RAID volume. The following prompt appears:



**Step 3.** Press <Y> key to accept the volume deletion.




### WARNING!

Deleting a RAID configuration also destroys all data stored on it.

---

## 1-3. Reset Disks to Non-RAID

**Step 1.** Select option 3 **Reset Disks to Non-RAID** and press <Enter> to delete the RAID volume and remove any RAID structures from the selected disk drives. The following screen appears:



**Step 2.** Press the <Space> key to select disk drives, press <Enter> to complete your selection, and press <Y> key to confirm.



### WARNING!

1. Resetting disks to non-RAID destroys all data on the RAID drives and the internal RAID structures when you perform this operation.
2. The only time you perform "Reset Disks to Non-RAID" is when you want to re-configure an incompatible RAID configuration or trying to reuse disk drives in a failed volume.


## Software Installation

### Installation Options:

1. Install OS on an IDE disk drive and configure the connected SATA disk drives into RAID volumes using the connected SATA disk drives. You can use Intel's Matrix Storage Manager software for RAID configuration.
2. Install OS on SATA disk drives. To do so, you need to:
  - 2-1. Configure SATA drives into RAID volume using the Intel BIOS configuration utility.
  - 2-2. Use the associated Intel Floppy Configuration Utility to create a floppy drive that provides necessary installation driver during the OS installation process.
  - 2-3. Make you apply Intel chipset INF update utility before installing Matrix Storage Manager.
  - 2-4. You may install and use Intel's Matrix Storage Manager software as a monitoring or configuration utility.

### Installation Steps:

- Step 1.** Boot from the OS installation CD-ROM. Press the <F6> key when the lower screen message "Press F6 if you need to install third-party SCSI or RAID driver" appears.
- Step 2.** When the following screen prompts, press <S> to specify the location of additional driver.



**Step 3.** Provide the driver diskette you separately prepared, Intel 82801GR SATA RAID Controller Driver for ICH7R in the drive: A floppy, and press <Enter> to proceed.

**Step 4.** Select the driver “Intel ® 82801GR SATA RAID Controller from the selection prompt. Press <Enter> to confirm.



**Step 5.** Press <Enter> to continue with the rest of the OS installation process.

### Confirming Windows XP/2000 Driver Installation

- Step 1.** Open the **Control Panel** from **My Computer**, and then click on the **System** icon.
- Step 2.** Select the **Hardware** tab, and then click the **Device Manager** tab to display system components.
- Step 3.** Click the “+” mark at the **SCSI and RAID Controllers** hardware category to display the name of installed components. Check if the driver **Intel® NH82801GR SATA RAID Controller** is listed.

### Intel Matrix Storage Console

The Intel Storage Manager consists of the following components:

- z Intel Matrix Storage Manager Driver
- z Intel Matrix Storage Console
- z Event Monitor
- z Intel Matrix Storage Manager Option ROM


Note that the option ROM is typically integrated with system BIOS before the operating system is loaded.

#### Installation Steps:


- Step 1.** Locate and double-click the iata55\_enu program to begin the installation process. The process should start as follows:




- Step 2.** When prompted by the welcome screen, click on the Next button to proceed with the installation.




- Step 3.** A window shows a list of components to be installed. Click the Next button to continue.




- Step 4.** After reading the license agreement as shown below, click Yes to proceed.



- Step 5.** Select the destination folder to which the program will be installed in the window shown below, and click Next to begin installation.



- Step 6.** Specify a program folder in which you want to place the program icon. Click Next to proceed. When the file copying process is completed, the following window should appear.




The program installation should take effect after system reboot.

## Intel Matrix Storage Rebuild

### The Symptoms


If a disk drive member in a fault-tolerant RAID configuration fails, the operating system should operate normally. However, the read/write I/O performance should be lower for the additional resources consumed for retrieving data from the degraded array.

When a drive fails, a message should prompt indicating a hard drive has failed.




Another way to view the RAID volume status is to open the Matrix RAID Console program.

In the Basic mode, a drive failure will be indicated like this:



A failed drive will be grayed out and indicated by a cross-out sign.

In the Advanced mode, a failed drive will be indicated as a failed or missing hard drive from a list of RAID array components. The Matrix Storage Console recognizes hard drives by its physical connections. In Matrix Storage Console, hard drives are numbered 0 to 3. These numbers correspond the physical connections to the SATA1 to SATA4 on the CPU board. A hard drive connected to the SATA2 port will be recognized as drive 1.




## The Rebuild Process

A failed drive should immediately be replaced because if yet another drive fails in a RAID5 array, all data stored on the array will be lost. A RAID0 array provides no data redundancy. Any failed drive will destroy the RAID volume. A RAID1 array that consists of four drives can withstand two drives to fail, provided that these two drives cannot belong to a mirrored pair.


The Matrix RAID Manager automatically rebuilds a RAID array once a removed/failed drive is restored.

Because the Matrix RAID operates transparently to the operating system, once a failed drive is replaced the array status will be indicated as normal.



The rebuild process runs in the background and completes without user's interventions.

To ensure that the rebuild process has started, you have to check in the RAID volume window. Once the array is selected, you should be able to see the rebuild progress on the right-hand-side status window.



Appendix

**E**

# External AC'97 Audio CODEC

---

## Introduction

The audio functionalities of the 3301570 CPU card can be implemented using a separately purchased audio module, the AC-KIT08R-R10. The audio kit is powered by a Realtek ALC655, which is a 16-bit, full duplex AC'97 2.3 compatible audio CODEC with 48KHz sampling rate. The audio kit functionalities are interfaced through three (3) phone jack connectors and two (2) pin headers including:

1. A LINE input shared with surround output
2. A MIC input shared with Center and LFE output
3. A LINE output
4. Analog line-level stereo inputs with 5-bit volume control: CDIN1 and AUXIN1. Both

Front\_out and Surround\_out are equipped with a built-in 50mW/20ohm amplifier. The ALC655 supports host/soft audio from Intel ICHx chipsets as well as audio controller based VIA/SIS/Ali/ATI chipset with bundled Windows series drivers (XP/ME/2000/98/NT), EAX/Direct Sound 3D/I3DL2/A3D compatible sound effect utilities supporting Karaoke, 26 kinds of environment sound emulations with 10-band equalizer, and HRTF 3D positional audio. The audio kit provides an excellent entertainment package sufficient for today's multimedia systems.





Figure E-1 Audio Functionalities via the Audio Kit

## Physical Connection



**Figure E-2 Audio Kit Connectors**

The audio kit comes with a PCI slot bracket for the installation into a PC case or rackmount chassis. Connect the 10-pin header to the 3301570's AUDIO1 header as shown in Figure E-1, and if necessary, connect the CDIN1 and AUXIN1 to optical drives or other audio sources, e.g., an MPEG card, using a 4-pin cable. Note that depending on the devices you connect to, the phone jacks have different functions with different audio installation modes (2 channel or 5.1 channel modes).

## Driver Installation

### Locating Audio Driver in the AUDIO IC Folder


This folder contains the installation programs for Realtek's AC'97 audio functions and configuration utility, which allows you to configure the functionalities provided by the onboard Realtek audio chip.

To install the utility, locate and run the "WDM\_A380" installation program under the "REALTEK" ->


“AC655” sub-folder. An installation wizard will guide you through the rest of the installation steps.




The A3.64 (or later revision) folder contains the installation program for Realtek Media Player, which is an optional feature and will not be discussed in the following sections.



When the InstallShield is loaded, click on the Next button to proceed.




The installation program will then start to configure software installation.




When prompted by the Windows Logo Testing message, click “Continue Anyway” to proceed.



Upon the completion of the installation process, you will be prompted with a request to reboot your system.




After reboot, you should be able to find the sound effect configuration utility in Windows Control Panel; and if peripheral speakers have been properly connected, hear the sound effects.



## Sound Effect Configuration

After installing the audio CODEC driver, you should be able to use the multi-channel audio features now.

Click the audio icon from the Notification Area from system task bar. The shortcut to the configuration utility is also available through the **Sound Effect Manager** icon in the **Control Panel**.




Sound Effect Manager



### Sound Effect

You may select a pre-configured sound environment setting with the preset equalizer settings.


You may also load an equalizer setting or make a new equalizer setting using the **“Load EQ Setting”** and **“Save Preset”** button.




## Environment Simulation

This is the default screen whenever the configuration utility is opened.

You may select different sound environment modes by a single click on the Environment pull-down list. There are a total of 23 preset environment modes. You may also fine-tune the environment setting by clicking the **Edit** button on the right, which displays an editor window. Select a preset mode you want to edit. Select a preset mode, and then select one the property value from the list below by a single click. Use the scroll bar below to adjust properties setting. When the adjustment is done, click the Save button to proceed.



## Karaoke Mode



The Karaoke mode allows you to eliminate the vocal of the music you play or adjust the key to accommodate your range.

The configuration options that come with the Karaoke function include:

1. **Voice Cancellation:** This checkbox, when selected, disables the vocal part of the music you play in your computer while the background music remains.
2. **Key adjustment:** Use the Up or Down arrow icons to find a key that fits your vocal range.




### NOTE:

The Equalizer button on the default display brings you to the same configuration window as the Equalizer function tab on top of the window.


---

## Equalizer Selection



The equalizer allows users to change sound effect parameters. The default screen shows equalized values. You may also select preset modes from the buttons below. The configurable values include 10 bands of equalizer ranging from 100Hz to 16KHz. Use the scroll bar to fine-tune, and use the **Load**, **Save**, **Delete**, and **Reset** buttons to edit your settings.

## Speaker Configuration



In this functional window, you can configure your multi-channel speaker settings.

Select the audio configuration from the **No. of Speakers** section on the left by clicking on one of the check circles.

The configurable options are:

1. Headphone
2. 2 channel mode for stereo speaker output
3. 4 channel mode for 4 speaker output
4. 6 channel mode for 5.1 speaker output
5. Synchronize the phonejack switch with speakers settings


Select a speaker configuration by selecting its check circle, and then click **OK** to apply the configuration change.

Connect your speakers to the corresponding phonejacks. It is recommended you write down your configuration, power off the system, and then complete the physical connections.

Select from the **Phonejack Switch** section if you want to re-define the phonejacks. Click the

specific phonejack button for several times to change its input/output functionality.

## Speaker Test



This functional window allows you to test each connected speaker if your 4- or 6-channel audio operates properly. If any speaker malfunctions, you should then check the cabling or replace the malfunctioning parts.

Select each specific speaker to test its functionality. The speaker you select will be highlighted and sound should be generated.



### NOTE:

1. The test scenario that appears in the **Speaker Test** window corresponds to the number of speakers you selected in the **Sound Effect** window.
  2. You should select and deselect the **Swap Center/Subwoofer Output** check box to see if these two devices properly work.
-

## S/PDIF-In & S/PDIF-Out

These functions are currently not supported.


## Connector Sensing




Realtek ALC655 supports Jack Sensing functionality. If an audio device is plugged into the wrong connector, a warning message will display informing users to correct the physical connections.

Click the Start button to start the sensing. Please remember to close all running audio-related programs before executing the sensing operation.

The EZ-Connection screen shows the result of sensing test.




The “Audio Connector” column shows the settings used in the “Speaker Configuration” window. The “Current Connection” column shows the types of devices detected during test. If the result does not match the physical connection, an exclamation mark will appear.



After closing the EZ-Connector screen, the following window should appear showing the latest connection status.

## HRTF Demo




This window allows you to adjust your HRTF (Head Related Transfer Functions) 3D positional audio before playing 3D applications. Select a preferred **Environment** mode and/or different **Sound** and **Moving Path** settings.

## Microphone Effect

This window provides an option, Noise Suppression. Select its check box to enable this functionality.

## General

This window provides information about this AC'97 audio configuration utility including **Audio Driver** version, **DirectX** version, **Audio Controller**, and **AC'97 Codec**. You may also change the language of this utility through the **Language** pull-down menu.



# Index



1

1<sup>st</sup> Boot Device, 4-24

1<sup>st</sup> Drive, 4-25

3

32Bit Data Transfer, 4-10

7

775-pin Socket, 3-8

9

945G Express, 2-3

945G Express Chipset, 1-5

A

ACPI APIC support, 4-14

ACPI Configuration, 4-14

Add On ROM Display Mode, 4-24

Address Mapping, B-1

Advanced, 4-6

Advanced ACPI Configuration, 4-14

Advanced Resume Event Controls,  
4-17

AHCI, 4-9

Allocate IRQ to PCI VGA, 4-21

AMI BIOS, 4-5

AMI OEMB table, 4-15

APCI 2.0 Features, 4-14

APIC ACIP SCI IRQ, 4-15

APM Configuration, 4-16

ATA(PI) 80Pin Cable Detection, 4-10

ATA/IDE Configuration, 4-8

ATX Control, 3-15

ATX Power, C-1

ATX Power Switch, C-3

ATXCTL, 2-7, 2-8

Audio, 1-7, 2-7

Audio Controller, 4-28

Audio Port, 2-15

B

backplane, 2-2

Backplane, 1-3

BIOS, 1-7, 4-1

BIOS EHCI Hand-Off, 4-18

BIOS Menu, 4-4

Block, 4-10

Block Diagram, 2-4

Boot, 4-23

Boot Device Priority, 4-24

Boot From LAN, 4-24

Boot Sector Virus Protection, 4-26

Boot Settings Configuration, 4-24

Bootup Num-Lock, 4-24

bus speed selection, 2-5

C

Cables Included, 3-14

Change Supervisor Password, 4-26

Change User Password, 4-26

chassis, 2-2

Chipset, 1-5, 4-27

Chipset ACPI Configuration, 4-15

Clear CMOS, 3-5

Clear NVRAM, 4-20

CN1, 3-7

CN2, C-2

COM, 2-7

COM Port, 2-14

Configure DRAM Timing by SPD, 4-27

Cooling Kit, 3-12

CPU, 1-5, 2-2

CPU 12V, 2-8

CPU 12V power source, 3-11

- CPU Board, 1-2
  - CPU Configuration, 4-7
  - CPU fan connector, 3-11
  - CPU Fan Target Temperature, 4-13
  - CPU Installation, 3-8
  - CPU socket, 3-9
  - CPU speed, 1-2
  - CPU\_fan, 2-7
  - CPU\_FAN, 2-16
  - CPU12V, 2-7
  - CPU-related information, 4-7
- D**
- DDR2, 1-2
  - Digital I/O, 2-13
  - DIMM, 3-3, 3-14
  - DMA Channel#, 4-22
  - DMA Mode, 4-10
  - DOS environment, A-2
  - Dual Channel Memory, 3-3
  - Dual-Core, 2-2
- E**
- electrostatic discharge, 3-2, 3-8
  - Energy Lake Feaure, 4-15
  - Enhanced Mode, 4-8
  - Ethernet, 1-6, 2-5
  - Example program, A-3
  - Exit, 4-30
  - external interfaces, 2-6
  - External Switches, 3-7
- F**
- FAN1, 2-9
  - FDD, 2-7
  - FDD (Floppy), 2-11
  - Floppy, 1-6
  - Floppy Configuration, 4-11
  - Form Factor, 1-7
- G**
- GbE, 2-7
  - GbE Ethernet, 2-18
  - General ACPI Configuration, 4-14
  - Graphics, 1-5
- H**
- Hard Disk Drives, 4-25
  - Hard Disk Power Down Mode, 4-16
  - Hard Disk Write Protect, 4-10
  - Hardware Health Configuration, 4-13
  - Hardware monitor, 1-6
  - Hardware Monitor, 2-5
  - Headless mode, 4-15
  - heatsink, 3-11
  - Heatsink, 3-13
  - Hit 'DEL' Message Display, 4-24
  - HT functionality, 3-3
  - Hyper-Threading Technology, 4-7
- I**
- I/O Controller, 1-7
  - ICH7R, 1-2
  - IDE, 2-7, 2-10
  - IDE Configuration, 4-8
  - IDE Detect Time Out, 4-10
  - IDE interface, 1-5
  - Indicators, 3-7
  - Initiate Graphic Adapter, 4-27
  - Installation Notices, 3-2
  - Intel Matrix Storage Manager, D-2
  - Intel RAID Option, D-2
  - Interface Connectors, 2-7
  - Internal Graphics Mode Select, 4-27
  - Interrupt 19 Capture, 4-24
  - IrDA, 2-7
  - IrDA Infrared, 2-8
  - IrDA port, 1-6

IRQ, 4-22

IRQ#, 4-21

## J

JP1, 3-5

Jumper Settings, 3-5

## K

KB/MS, 2-13

Keyboard & PS/2 Mouse, 4-16

## L

L2 cache, 1-5

LAN Port LED, 2-18

LBA/Large Mode, 4-9

Legacy IDE Channels, 4-9

Legacy USB Support, 4-18

load lever, 3-9

load plate, 3-9

LPT, 2-7

LPT1, 2-12

## M

Main, 4-5

Matrix Storage, 2-5

Max CPUID Value Limit, 4-7

Memory, 1-5, 2-3

MPS Configuration, 4-18

MPS Revision, 4-18

Multi-Sector Transfer, 4-10

## N

Non-RAID, D-9

North Bridge Configuration, 4-27

## O

OffBoard PCI/ISA IDE Card, 4-21

On Board Floppy Controller, 4-11

Onboard LAN1 Controller, 4-28

Onboard LAN2 Controller, 4-28

Operating temperature, 1-7

OSes, 1-2

## P

Palette Snooping, 4-21

Parallel Port, 2-12

Parallel Port Address, 4-11

Parallel Port IRQ, 4-12

Parallel Port Mode, 4-12

PCI Express, 2-5

PCI Express Interface, 1-5

PCI IDE BusMaster, 4-21

PCI Latency Timer, 4-21

PCI masters, 2-5

PCI-E GbE Ethernet, 1-2

PCIE High Priority Port, 4-29

PCIE Port#, 4-29

PCI-E ports, 2-5

PCIE Ports Configuration, 4-29

PCIMG, 1-2

PCIPnP, 4-20

PEG Force x1, 4-28

PEG Port Configuration, 4-28

Pentium® 4, 1-2

Pentium® D, 1-2

Peripherals, 1-6, 3-14

PICMG, 2-5

PIO Mode, 4-10

Plug & Play O/S, 4-20

Power Button Mode, 4-17

Power Management/APM, 4-16

Power Switch, C-2

Primary and Secondary, 4-9

Processor, 4-5

protective cover, 3-9

PS ON connector, C-2

PS/2, 2-17

PS/2 Mouse Support, 4-24

## Q

Quick Boot, 4-24

Quiet Boot, 4-24

## R

RAID, 4-9, D-1

RAID Volume, D-3

Rear Panel, 2-17

Remote Access Configuration, 4-18

Removable Drives, 4-25

Reserved Memory Size, 4-22

Restore on AC Power Loss, 4-17, 4-28

Resume On LAN, 4-17

Resume On PME#, 4-17

Resume On Ring, 4-17

Resume On RTC Alarm, 4-17

## S

Security, 4-26

Serial ATA, 1-6, 2-14, 2-15

Serial Port1 Address, 4-11

Serial ports, 1-6

SMART Monitoring, 4-10

SMBUS Controller, 4-28

South Bridge Chipset Configuration,  
4-28

static free installation environment, 3-8

Stripe size, D-5

Super IO Configuration, 4-11

Support Bracket, 3-13

Supported CPUs, 2-2

Suspend Time Out, 4-16

System Date, 4-5

System Memory, 4-5

System Monitoring, 1-7

System Time, 4-5

## T

Type, 4-9

## U

Unpacking, 3-4

USB, 2-16

USB 2.0, 1-6, 2-18, 4-28, 5-1

USB 2.0 Controller, 4-18

USB Configuration, 4-18

USB Function, 4-18

USB Functions, 4-28

USB2.0 Controller Mode, 4-18

## V

VGA, 2-7, 2-18

Video Power Down Mode, 4-16

## W

Wait For 'F1' If Error, 4-24

Watchdog Timer, A-1

Any advice or comments about our products and service, or anything we can help you with please don't hesitate to contact with us. We will do our best to support you for your products, projects and business

### **Global American Inc.**

Address: 17 Hampshire Drive  
Hudson, NH 03051

TEL: Toll Free (U.S. Only) 800-833-8999  
(603)886-3900

FAX: (603)886-4545

Website: <http://www.globalamericaninc.com>

E-Mail: [salesinfo@globalamericaninc.com](mailto:salesinfo@globalamericaninc.com)

